




USER MANUAL



FULL-STORAGE SHELF

 **WARNING!** Read this manual carefully before use

SCOPE OF APPLICATION

This children's shelving unit is designed for the safe and convenient storage of books, toys, learning materials, and small personal items. It is intended for use by children aged 2 and up, encouraging independent organization and easy access to everyday essentials.

Recommended age: For children from 2 to 6 years old.

Maximum Load Capacity: 30 kg / 66 lbs.

TERMS OF USE

- Only for indoor use.
- For domestic use.
- Tighten the bolts every 2 months.
- Use not more than 1 rope accessory per time.
- A safety mat or soft landing area is recommended to minimize injury risks.
- The product has no expiration term but change the product or the details of the product immediately if any damage occurs.
- 2 years warranty.

Note:

- Warranty does not apply if the product is being damaged due to the weather conditions, as it is for indoor use only;
- Manufacturer reserves the right to make structural changes to the product without prior notice, provided such changes do not affect product's functionality, safety, and key features;
- In case of any inappropriate use or failure to comply with the instructions, the manufacturer and seller shall bear no responsibility and the warranty shall not apply.
- Responsibility for any damage incurred by children during play on the furniture rests with the supervising adults; if a child is injured while playing with the product, please treat the wound and consult a doctor.



SAFETY MEASURES





















- The product must be assembled by an adult; do not try to assemble the product without following the manufacturer's instructions: improperly assembled product can be unstable and unsafe.
- In disassembled state the product contains small parts constituting a choking hazard for the kid; after the assembly, ensure all screws and fastenings are securely tightened; put the spare screws, if any, out of the reach of children.
- To be used under the direct supervision of an adult only; do not leave the kid alone with the product.
- Tighten the screws every 2 months and regularly check the product for signs of wear; immediately stop the use of the product if it has any.
- Do not exceed the maximum weight limit.
- Do not let children to climb onto the construction - it is meant for storage, not climbing.
- Do not use at uneven and hard floor.
- Do not use the product if it has any visible damage or positioned abnormally.
- Do not use the product on the wet or contaminated floor.
- Do not place near hazards: ensure the climber is located at least 2m away from windows, sharp corners, hard furniture or any other hazard.
- Do not place the product close to the sources of radiant heat or under the direct sun rays.
- To ensure the stability of a construction and prevent overturning, securely anchor the structure to the floor with the anchors that are added to the assembly kit.

CARE AND MAINTENANCE

- To clean the item, wipe it with a damp cloth or wet wipes.
- Avoid excessive moisture - water can penetrate into seams or microcracks and cause damage to wood; in case of spillage on the product - wipe dry.
- Do not use abrasive sponges, aggressive detergents, alcohol or acetone.
- Do not leave the product outdoors or near heat sources (batteries, fireplaces).
- With the appearance of scuffs or fading, you can easily restore a layer of varnish or paint - use the same water base that the product was treated with. Clean the surface and grind lightly before re-coating.
- If the product is not used for a long time, store it in a dry room with moderate humidity (40-60%); avoid storage in damp or uninsulated areas.

ASSEMBLY INSTRUCTIONS


1 - Side panel  2 pcs.	2- Back wall of the lower drawer  1 pc.	3 - Front lower leg  1 pc.	4 - The base of the lower drawer  1 pc.
5 - Side wall of the lower drawer  2 pcs.	6 - Divider  5 pcs.	7 - Front wall of drawers 2 and 3  2 pcs.	8 - The base of drawers 2 and 3  2 pcs.
9 - Back wall of drawers 2 and 3  2 pcs.	10 - Side wall of the middle box  2 pcs.	11 - Side wall of the upper drawer  2 pcs.	a - Conformat screw 5x40  51 pcs.
b - 3mm Hex key  1 pc.	c - Ericson Nut M6x9  12 pcs.	d - Screw M6x20  12 pcs.	e - 4mm Hex key  1 pc.
f - 5mm Hex key  1 pc.			




Assemble the upper box: take the the base of drawers 2 and 3 (8) and screw the dividers (6) to it with the help of confirmats (a) and

Then screw the back wall of drawers 2 and 3 (9) to dividers (6) with confirmats (a). Screw sidewalls of the upper drawer (11) to the base of drawers 2 and 3 (8) with confirmats (a). Screw the front wall of drawers 2 and 3 (7) to the previously assembled structure with confirmats (a). See Pic.1.a hex key (b).


Assemble the middle and lower drawers in the same way, using for each their own side walls.



2



Screw previously assembled drawers to the side panel (1) using screws (f) by holding it with the hex key (e). Fix the screw with the nut (c) from another side with the help of hex key (f). See Pic. 2.



Screw the second side panel (1) to the previously assembled structure using the screws (d) by holding them with hex key (e). Fix the screw with the nut (c) from another side by holding it with the hex key (f). See Pic. 3.

DISPOSAL AND ENVIRONMENTAL INFORMATION

Dispose of the product in accordance with local waste regulations. Components can be recycled where applicable.

MANUFACTURER

Look for manufacturer information on the product packaging.

CONTACT INFORMATION

- ☎ + 1 804-500-1025 (USA, EN)
+ 38 050 067 71 15 (UA)
- ✉ unterstutzung@woodandhearts.de
support.official@woodandhearts.com
- 🌐 woodandhearts.de
woodandhearts.com