



K6 Pro Bluetooth Mechanical Keyboard

IN THE BOX:

Keychron K6 Pro Bluetooth Mechanical Keyboard x 1

Type-C Cable * 1

Manual * 1


Quick Start Guide * 1

Extra Keycaps Set * 1

Quick Start Guide

If you are a Windows user, please find the appropriate keycaps in the box, then follow the instructions below to find and replace the following keycaps.


Mac / Windows



1 Connect Bluetooth



Switch toggle to Bluetooth




Press fn1 + Q (for 4 seconds) and pair with device named Keychron K6 Pro.



2 Connect Cable



Switch toggle to Cable



3 The VIA Key Remapping Software

Please visit caniusevia.com to download the latest VIA software to remap the keys. If the VIA software cannot recognize your keyboard, please reach out to our support to get the instruction. (VIA only works when the keyboard is connected by wire to the computer.)




4 The Layers


There are five layers of key settings on the keyboard. The layer 0 is for the Mac system. The layer 1 is for the Windows system. The layer 2 is for the Mac Multimedia keys. The layer 3 is for the Windows Multimedia keys. The layer 4 is for the Function keys.



If your system toggle is switched to Mac, then the layer 0 will be activated.




If your system toggle is switched to Windows, then the layer 1 will be activated.




5 Multimedia Key and Function Key


Multimedia keys



Function keys


F1 / F2 / F3 / F4 / F5 / F6 / F7 / F8 / F9 / F10 / F11 / F12

In order to get Multimedia Key, you need to press fn1 and  Key.

In order to get Function Key, you need to press fn2 and  Key.


6 The Backlight

Press fn1 + A to change the lighting effect



fn1 + A


Press fn1 + caps lock to turn the backlight on/off



fn1 + caps lock


7 Adjust The Backlight Brightness

Press fn1 + S to increase the backlight brightness



fn1 + S

Press fn1 + X to decrease the backlight brightness



fn1 + X

8 Warranty

The keyboard is highly customizable and easy to be rebuilt. If anything goes wrong with any of the keyboard components of keyboard during the warranty period, we will only replace the defective parts of the keyboard, not the whole keyboard.




9 Watch The Building Tutorial On Our Website

If you are building the keyboard for the first time, we highly recommend you watch the building tutorial video on our website first, then start building the keyboard yourself.



10 Factory Reset



Troubleshooting? Don't know what's going on with the keyboard?

- ① Try factory reset by pressing fn2 + J + Z (for 4 seconds).
 - ② Download the right firmware for your keyboard from our website.
Remove the power cable from the keyboard.
 - ③ Remove the space bar keycap to find the reset button on the PCB and switch the keyboard to cable mode.
 - ④ Hold the reset key while plugging in the power cable and then release the reset key. The keyboard now will enter DFU mode.
 - ⑤ Flash the firmware with the QMK Toolbox.
 - ⑥ Factory reset the keyboard again by pressing fn2 + J + Z (for 4 seconds).
- * Step by step guide can be found on our website.

K6 Pro Bluetooth Mechanical Keyboard Specifications

Number of keys: 68

Switch type: Mechanical

Battery: 4000mAh

Working time: 20 - 80 hours RGB lighting - varies with brightness and usage

Charging time: Around 3 hours

Charging port: USB Type-C

Mode: Bluetooth/Wired

Bluetooth operating distance: Within 10 meters (open space)


Name of Bluetooth device: Keychron K6 Pro

Operating Environment: -10 to 50°C



Technical specifications can be subjected to change without notice, we apologize for any inconvenience caused.

K6 Pro Bluetooth Mechanical Keyboard Overview

Mac




Windows




- ① Charging port
- ② Charging indicator
- ③ Win/Android
Mac/iOS (OS Toggle Switch)
- ④ BT OFF Cable
(Mode Toggle Switch)

DEFAULT KEY LAYOUT:

LAYER 0: This layer will be activated when your keyboard's system toggle is switched to Mac.




LAYER 1: This layer will be activated when your keyboard's system toggle is switched to Windows.




LAlt = Left Alt LWin = Left Windows RAlt = Right Alt


LAYER 2: This layer will be activated when your keyboard's system toggle is switched to Mac and press the fn1/MO(2) key.



LAYER 3: This layer will be activated when your keyboard's system toggle is switched to Windows and press the fn1/MO(3) key.



LAYER 4: This layer will be activated when you press the fn2/MO(4) key.



KEY DESCRIPTION

Key Description	
Scr-	Screen Brightness Decrease
Scr+	Screen Brightness Increase
Bright-	Backlight Decrease
Bright+	Backlight Increase
Prvs	Previous
Play	Play/Pause
Next	Next
Mute	Mute
Vol-	Volume Decrease
Vol+	Volume Increase
RGB Toggle	Turn Backlight on/off

Key Description	
RGBMd+	RGB Mode Next
RGBMd-	RGB Mode Previous
Hue+	Hue Increase
Hue-	Hue Decrease
RGB SPI	RGB Speed Increase
RGB SPD	RGB Speed Decrease
MO(1)	Layer 1 will be activated when holding this key
MO(2)	Layer 2 will be activated when holding this key
MO(3)	Layer 3 will be activated when holding this key
MO(4)	Layer 4 will be activated when holding this key

LED STATUS OVERVIEW

LED Location	Function	Status
Battery indicator	Charging	Low battery - Blinking Red Charging - Static Red Fully charged - Static Green
Bluetooth indicator	Bluetooth	Pairing - Slow Blinking Paired - Light Off Switching - Fast Blinking

FUNCTION DESCRIPTION: CHARGING

Plug the cable into a USB port and plug the other end into the keyboard port. Charging Indicator: When battery is below 15%, a red battery blinking indicator will be triggered. A red light will stay on while charging; Fully charged in around 3 hours, a green battery indicator will appear.

*The Keychron keyboard is compatible with all USB ports. Please use a 5V 2A adapter or USB 3.0 for the best performance. The Keychron K6 Pro can be charged in Bluetooth/on/off mode.

** This product supports up to 5V charging voltage and 2A charging current. We are not responsible for any problems caused by improper charging.

BLUETOOTH/WIRED MODE (TOGGLE SWITCH)

WIRED MODE

1. Switch the toggle switch to Cable option (it only works when a USB cable is plugged in).
2. Connect our cable with your PC and keyboard.
3. Backlit will be turned on.

*Under Wired Mode, keyboard will not enter into Battery Saver Mode.

BLUETOOTH MODE

1. Switch the keyboard to Bluetooth option.
2. Backlit will be turned on.
3. Hold "Fn1+Q" key for 4 seconds to activate Bluetooth pairing (the Bluetooth indicator fast flashes for 3 minutes to detect pairing).
4. Search for the Bluetooth device "Keychron K6 Pro" on your device and connect it (the Bluetooth indicator goes off after successful pairing).

Note: This keyboard supports pairing up to 3 devices simultaneously via combination key "fn1" + "Q" / "fn1" + "W" / "fn1" + "E". Simply short press combination keys "fn1" + "W" / "fn1" + "E" to switch. Follow the above procedures to connect with other devices.

**The Bluetooth indicator will continue to flash for 3 minutes.*

***Slow or failed connections may exist due to different Bluetooth versions, please make sure all the settings are correct.*

SWITCH BLUETOOTH DEVICES

Short press combination key "fn1" + "Q" / "fn1" + "W" / "fn1" + "E" to switch to other device.

Reconnect:

1. Switch the keyboard to the Bluetooth option to activate the keyboard (the keyboard will connect to the last connected device by default).
2. The Bluetooth indicator flashes for 3 seconds and automatically pairs with the last paired device.
3. If the Bluetooth indicator is off, press any button to enter the connection again.

* The keyboard must have been paired with the device to perform this function.

Turn off the Keyboard

Switch to "Off"

BACKLIT SETTING

- Short press  to switch between different types of lighting effects.
- When backlit is on, press  button to switch among them.

OS SWITCH

1- MAC/iOS

Turn the switch to Mac/iOS when you are connected to a Mac or iOS operating system.

2-WINDOWS/ANDROID

Switch the toggle to Windows/Android when the keyboard is connected to a Windows or Android operating system.

*When using the Windows/Android mode,   keys are used for "Windows" and "Alt" functions.

3—INPUT METHOD SWITCH

For iOS:

Input method switch: Ctrl + Space

Caps Lock: Caps (Enable General>Keyboards>Hardware Keyboard>Caps Lock Language Switch)

For Android:

Input method switch: Shift + Space

NOTE: Functions of certain multimedia key may be disabled due to compatibility, versions, brands and drivers of Windows/Android OS. We also recommend not to switch OS frequently as it may impact keyboard operations.

TROUBLESHOOTING

If unable to pair keyboard to device, confirm that the device you're trying to pair with is Bluetooth-capable. If so, restart the device and try pairing it with the keyboard again.

Note: On a Windows computer, a new Bluetooth connection will sometimes require additional software updates—a process that may still be ongoing after a message appears indicating a successful completion. Wait at least 20 minutes after pairing to make sure all updates are completed before restarting the computer.

Confirm that the device is configured to accept Bluetooth connections (Windows) and supports an external keyboard (HID profile).

Go to Bluetooth Devices > Open Settings and select the following:

Allow Bluetooth devices to find this computer

Allow Bluetooth devices to connect to this computer

Alert me when a Bluetooth device wants to connect

My keyboard isn't working.

For the keyboard: Turn the keyboard off and back on.

Turn Bluetooth off and restart the computer. (Windows)

For the device:

Go to Bluetooth settings and turn off Bluetooth and “forget” the keyboard.

Restart the device and turn on Bluetooth to reconnect.

Bluetooth connection is interrupted even within 10 meter.

Check if the keyboard is resting on a metal surface that can interfere with the Bluetooth signal.

Third party input tools are not compatible with the keyboard.

Due to compatibility, versions, brands and drivers of Windows/Android OS, functions of third party input tools may be affected while using the keyboard. Please make sure your operating system and drivers are up to date.

Certain fn keys or multimedia keys does not work under Windows/Android mode.

Functions of certain multimedia keys may be disabled due to compatibility, versions, brands and drivers of Windows/Android OS.

Safety Precaution:

Keep the product, accessories and packaging parts out of reach of children to prevent any accidents and choking hazards.

Always keep the product dry to avoid corrosion.

Do not expose the product to extreme temperatures below -10°C (5°F) or above 50°C (131°F) to preserve the lifespan of the keyboard and battery.

Keychron, Inc.
Dover, DE 19901, United States

Find us at:

<https://www.keychron.com>

Support@keychron.com

 @keychron

 @keychron

 @keychronMK

Designed by Keychron

Made in China



Keychron

K6 Pro 蓝牙机械键盘

内容清单

Keychron K6 Pro 蓝牙机械键盘

USB线 x 1

拔键器 x 1

赠送键帽套装 x 1


说明书 x 1

快速上手指南 x 1

快速上手指南

如果你是Windows用户, 请在包装盒里找到如下的键帽, 用拔键器拔下键盘上的对应键帽并且更换。


Mac / Windows




1 连接蓝牙



把开关拨到蓝牙模式




长按fn1+Q 四秒使键盘进入配对模式，
键盘的配对名为：Keychron K6 Pro。




fn1 + Q

2 连接有线



把开关拨到有线模式



3 关于VIA映射软件

可以访问 caniusevia.com
下载最新的VIA软件，
VIA是可以映射按键的软件。
如果VIA软件不能识别你的键盘，
请联系我们以获得技术支持。
(VIA 仅在键盘通过线连接到计算机时有效。)



4 关于键盘键层说明

键盘有五层按键设置。

层0是用于Mac系统

层1是用于Windows系统

层2是用于Mac系统多媒体

层3是用于Windows系统多媒体

层4是用于功能键



Mac系统多媒体

如果您的系统拨片切换到Mac档位，
层0将被激活




如果您的系统拨片切换到Win档位，
层1将被激活。



5 多媒体键和功能键

多媒体键



功能键

F1 / F2 / F3 / F4 / F5 / F6 / F7 / F8 / F9 / F10 / F11 / F12

按下 fn1 和



就能得到多媒体键。


按下 fn2 和



就能得到功能键。


6 更改键盘背光模式以及快速关闭/开启键盘背光

组合 fn1+A 键,更改键盘背光模式。



fn1 + A


组合 fn1+caps lock 键,可快速关闭/开启键盘背光。



fn1 + caps lock


7 调整键盘背光亮度

组合fn1+S键,提高键盘背光亮度。



fn1 + S

组合fn1+X键,减少键盘背光亮度。



fn1 + X

8 保修

由于K6 Pro客制化键盘是可高度定制且易于组装的,
所以键盘的任何一个部件出了问题,
我们只会更换键盘有问题的部件而不是整个键盘。




9 键盘组装教程

如果您没有安装过类似产品的经验，我们建议您观看我们网站上的键盘组装教程视频，然后再开始进行键盘组装。



10 恢复出厂模式



如果键盘出现了故障，不知道怎么办？

1. 依照顺序长按fn2+J+Z (等待四秒)；
2. 从我们的网站为您的键盘下载正确的固件，然后拔掉键盘上的数据线；
3. 拔掉空格键键帽，找到位于PCB上面的复位按钮；
4. 长按复位按钮同时插入键盘的数据线然后放开这个复位按键，此时键盘会进入DFU模式；
5. 然后您可以使用QMK工具箱进行刷新固件的操作；
6. 再次将键盘恢复出厂设置长按fn2+J+Z (等待四秒)。

* 步骤指南可以在我们的网站上找到。

K6 Pro 键盘规格

按键: 68键

轴: 机械轴

电池: 4000mAh

工作时间: 20 - 80小时RGB照明 - 随亮度和使用情况而变化

充电时间: 3小时

充电端口: USB Type-C



模式: 蓝牙/有线

蓝牙工作距离: 最长10米 (开放空间)


蓝牙设备名称: Keychron K6 Pro

K6 Pro 键盘概述

Mac



Windows



- ① 充电口
- ② 充电指示灯
- ③ Win/Android
Mac/iOS (OS切换开关)
- ④ BT OFF Cable
(连接模式切换开关)


功能说明

LED状态显示如下:


功能	LED位置	状态
充电	电源指示灯	低电量 - 红灯闪烁 充电 - 红灯长亮 满电 - 绿灯
蓝牙	蓝牙指示灯	快闪-切换 熄灭-连接成功 慢闪-配对

按键布局

层0: 当您的系统拨片切换到Mac档位的时候,层0将被激活使用。




层0: 当您的系统拨片切换到Windows档位的时候,层1将被激活使用。




LAlt = Left Alt LWin = Left Windows RAlt = Right Alt


层1: 当您的系统拨片切换到Mac档位并组合fn1/MO(2)键的时候,层2将被激活使用。



层3: 当您的系统拨片切换到Windows档位并组合fn1/MO(3)键的时候,层3将被激活使用。



层4: 当您长按fn2/MO(4)的时候,层4将被激活使用。



K6 Pro 客制化键盘多媒体按键说明

按键说明		按键说明	
Scr-	屏幕亮度-	RGBMD+	下一个RGB灯光模式
Scr+	屏幕亮度+	RGBMD-	上一个RGB灯光模式
Bright-	键盘背光亮度-	Hue+	下一个灯光颜色
Bright+	键盘背光亮度+	Hue-	上一个灯光颜色
Prvs	上一曲	RGB SPI	RGB灯光速度+
Play	播放/暂停	RGB SPD	RGB灯光速度-
Next	下一曲	MO(1)	按住MO(1), 层1将被激活
Mute	静音	MO(2)	按住MO(2), 层2将被激活
Vol-	音量-	MO(3)	按住MO(3), 层3将被激活
Vol+	音量+	MO(4)	按住MO(4), 层4将被激活
RGB Toggle	关闭/开启键盘背光		

充电

将电线插入USB端口，将另一端口插入键盘的端口

充电指示灯: 电池电量低于15%，红色电池指示灯快速闪烁; 充电时，红色电池指示灯常亮; 在约3小时内完全充电，指示灯绿色长亮。

* Keychron K6 Pro 键盘与所有USB端口兼容。要获得最佳信号和最快充电时间，建议采用USB3.0端口或5V-2A电源适配器。

* Keychron K6 Pro 可在蓝牙 / 开 / 关模式下充电。

* 有线模式下，充电指示灯不会熄灭。

* 本产品最高支持5V充电电压，和2A充电电流。因不当充电而产生的问题，我们概不负责。

背光灯

-短按  可切换背光效果。

蓝牙/有线模式

有线模式

1.将键盘“模式切换”拨动到 Cable 位置(没插USB线的时候键盘无任何反应)

2.使用本产品USB Type-C线连接电脑即可使用

3.键盘背光灯将打开。

*在有线模式下，键盘不会自动进入省电模式。

蓝牙模式

1.将键盘“模式切换”拨动到BT位置。

2.键盘背光灯将打开。

3.长按“fn1+Q”键 4 秒激活蓝牙配对(蓝牙指示灯闪烁3分钟)

4.在你的装置上搜索蓝牙装置“Keychron K6 Pro”并连接它(配对成功后蓝牙指示灯熄灭)。

注意:此键盘支持通过组合键“fn1+Q”/“fn1+W”/“fn1+E”依次配对最多3台设备,只需短按组合键“fn1+W”/“fn1+E”进行开关,按照上述步骤连接其他装置。

*因蓝牙版本较多等原因,初次连接可能出现连接缓慢或连接失败等问题,请耐心检查设备设置是否正确。

切换至蓝牙装置

短按组合键“fn1+Q”/“fn1+W”/“fn1+E”切换到其他装置。

* 切换过程可能会因切换频繁或切换速度过快, 导致延迟, 此时请耐心等待或重新切换。

回连

1. 将键盘切换到Bluetooth位置启动键盘 (键盘开机默认回连上次连接的设备)。

2. 蓝牙指示灯快闪3秒, 自动配对上一次配对的设备。

3. 如蓝牙指示灯熄灭, 可按任何按键再次进入回连状态。

* 键盘必须曾经配对该装置才能实现此功能。

关闭键盘

将“模式切换”拨至OFF, 此时本产品关闭所有模式, 但可以进行正常充电。

系统切换

1 - MacOS / iOS

连接到Mac或iOS操作系统时, 请将键盘左侧系统开关拨至Mac/iOS。

2—WINDOWS/安卓

当键盘连接到Windows 或 Android操作系统时, 请将键盘左侧系统开关拨至Win/Android。

3—输入法切换

对于iOS:

输入法切换: Ctrl + Space

大写锁定: Caps(启用常规>键盘>硬件键盘>大写锁定拉丁开关)

对于安卓:

输入法切换: Shift + Space

注: 由于Windows /安卓OS的兼容性、版本、品牌和驱动程序, 某些多媒体键的功能可能不能被使用。我们还建议不要频繁切换操作系统, 因为它可能会影响键盘的操作。

疑难排解

我无法将键盘与我的装置配对。

答:确认您要配对的装置可使用蓝牙。

重新启动装置并尝试再次与键盘配对。

注意:在Windows计算机上,新的蓝牙连接有时需要额外的软件更新 - 在出现表示成功完成的消息后,该过程可能仍在进行中。配对后至少等待20分钟,以确保在重新启动计算机之前完成所有更新。

确认装置配置可接受蓝牙连接 (Windows) 并支持外部键盘 (HID配置文件)。

转到蓝牙装置>打开设置,然后选择以下复选框:

允许蓝牙装置找到这台电脑

允许蓝牙装置连接到这台电脑

当蓝牙装置想要连接时提醒我

我的键盘无法使用。

答:关闭并重新打开键盘。

关闭蓝牙并重新启动计算机。

关于装置:

转到蓝牙设置并关闭蓝牙并“忘记”键盘。

重启装置,并打开蓝牙重新连接。

蓝牙连接或在10米内受干扰。

答:检查键盘是否放在可能干扰蓝牙信号的金属表面上。

第三方输入工具与键盘不兼容

答:由于Windows /Android系统的兼容性、版本、品牌和驱动程序,第三方输入工具在使用键盘时或被影响。请确保你的作业系统和驱动程序为最新版本。

某些fn键或多媒体键在Windows /安卓模式下不起作用。

答:由于Windows /Android系统的兼容性,版本,品牌和驱动程序,某些多媒体键的功能可能不能被使用。

注意事项:

请勿将本产品, 其配件和包装部件放在儿童接触到的地方, 以防发生意外引致窒息。

请保持产品干燥, 以免腐蚀。

请勿将产品暴露在低于-10°C (5°F) 或高于50°C (131°F) 的极端温度下, 以维持键盘或电池的使用寿命。

Keychron, Inc.

Dover, DE 19901, United States

<https://www.keychron.com>

通过以下方式与我们联系

Support@keychron.com

 @keychron

 @keychron

 @keychronMK

Keychron设计

中国制造

中国区总代: 渴创技术(深圳)有限公司

执行标准: GB/T 14081-2010

售后热线: 400-0766268

地址: 深圳市龙岗区坂田街道大发埔社区

大发路24号文坑工业区2栋201