



Original	Recharge	Original	Recharge
	Power		Power
	Source		AV / Input / RDS
	Ni cam / A2		Shift + Audio / Lang I / II
	Aspect		Zoom / Si ze
	P. Mbde		Pi cture / Format
	S. Mbde		Sound / Ti tle
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	-- / -		Shi ft + Gui de / - / -
	0		0
	Recal I		Back / Ret urn
	FAV		Fav / Marker / PC
	Freeze		Pause / Step / Freeze
	TV / Radi o		TV/ Radi o /
	Red		Red / Netf lix / Search
	Green		Green / APP / Repeat
	Yel low		Yel low / YouTube / Repeat
	Bl ue		Bl ue / Pri me Vi deo / Random
	Sl eep		Sl eep / Ti mer
	Up		Up
	EPG		Gui de / EPG / - / -
	Left		Left
	OK		OK
	Ri ght		Ri ght
	Menu		Menu / Home
	Down		Down
	Exi t		Exi t / Cancel / Clear



