



At a Glance



1	Bass Indicator	7	Bluetooth Indicator
	Bass Indicator Color: White		Bluetooth Indicator Color: Blue / White
2	Bass Button	8	Power Button / Power Indicator
3	Volume Down Button		Power Indicator Color: Red / White
4	Multi-function Button	9	USB Type C Port
5	Volume Up + Button	10	3.5mm Audio Input Port
6	Bluetooth Button		

Using Your Soundcore Motion+


1. Turn On / Off






ON	Press once
OFF	Press and hold for 2 seconds

Soundcore Motion+ is equipped with High-Resolution Audio. This specialty gives the speaker a better sound quality by referring to digital processes that allow playback of music using higher sampling rates. Note: Soundcore Motion+ supports Qualcomm® aptX™.

a. Bluetooth mode



	Slowly Flashing Blue (Fade in and out)	Bluetooth Pairing Mode Note: starts to connect to previous connected mobile device when speaker is turned on.
	Solid Blue	Connected to a device










	Enter True Wireless Stereo Group Mode / Disconnect True Wireless Stereo	
	Slowly	True Wireless Stereo Group Mode
	Solid White (Secondary speaker)	Connected to True Wireless Stereo
	Solid Blue (Primary speaker)	









- With True Wireless Stereo technology, you can pair your Soundcore Motion+ with another Soundcore Motion+ to explore the best sound effects with left and right sound channels separated on both speakers.

Music

 × 1	Play / Pause
 × 2	Play Next Song
 × 3	Play Previous Song
 × 1	Press to turn Bass on
 × 1	Press once to activate bass Note: Press again to switch back to Normal Equalizer
 > 2s	Activate Siri / Other Voice Control Software
	Volume Up / Down

Mobile phone


 × 1	Answer Call / End Call
 2"	Reject Call / Switch between a call on hold and an active call
 > 2s	End current call and answer incoming call / End current call and switch to call on hold
 > 2s	Switch audio source between Speaker and Phone

	Solid Blue	On a Call
	Flashing Blue	Incoming Call



- When turned on, Soundcore Motion+ will automatically connect to the last connected device if available. If not, press the Bluetooth button to activate pairing mode.
- To pair a different device, press the Bluetooth button to re-enter pairing mode. Then repeat the pairing steps.
- Having connection problems? Remove Soundcore Motion+ from your device's Bluetooth history and ensure it's less than 3 feet away. Then try pairing again. To get the best sound quality, make sure there is a clear line of sight between the connected device and your speaker.


b. AUX-In mode





- Plugging in an audio cable will automatically switch to AUX mode.
- When using AUX mode, control audio playback via the connected device.

Charging your Soundcore Motion+



	Slowly Flashing Red	Low Battery
	Solid Red	Charging
Off		Fully Charged



- Use the included USB cable to charge your Soundcore Motion+ and make sure it is fully charged before its first use.
- USB type C cable only supports charge in, it does not support charge out.
- Disconnect your speaker from the charger when fully charged. Do not charge your speaker for extended periods.
- When not in use, store your speaker in a cool place.

Specifications



Specifications are subject to change without notice.

Input: 5 V = 2 A

Audio output: 30 W

Battery capacity : max.6700mAh

Charging time : Approximately 4 hours(When power is off and the adapter must be at least 5V/2A)

Playtime (varies by volume level and music content): 12 hours

Size: 257 x 79 x 81 mm / 10.1 x 3.1 x 3.2 inch


Weight (without packaging): 1050 g / 37 oz

Bluetooth version: V 5.0

Bluetooth range: 30m/99ft

Sound Frequency Range: 50Hz~40kHz

soundcore APP



Google Play and the Google Play logo are trademarks of Google Inc.



Apple and the Apple logo are trademarks of Apple Inc.

Note: The 'x' of SN Code: xxxxxxxxxxxxxxxx is a variable, see below table.

Variable 'x'	Range of variable	Content
Seventh	0-9 or A-F	Denotes the hardware version which is not effected on the safety compliance.
Eighth	8,9,A,B,C...	Denotes the year, 8 means 2018, 9 means 2019, A means 2020, B means 2021, C means 2022, and so on.
Ninth and tenth	01,02,03...	Denotes weeks, 01 means the first week in this year, 02 means the secondary week in this year, and so on.
Eleventh	1-7	Denotes date, 1 means Monday, 2 means Tuesday..., 7 means Sunday and so on.
The last five	00001-99999	Denotes serial No.

1. Power consumption in standby mode: $\leq 0.5W$

2. Power management: $\leq 20min$

3. Information of applicable adapter:

Brand: ANKER

Manufacturer: Anker Innovations Limited

Model: A2337

Input: 100-240V~ 1.0A, 50-60Hz

Output: 5.0V \Rightarrow 3.0A 15.0W / 9.0V \Rightarrow 3.0A 27.0W / 12.0V \Rightarrow 2.5A 30.0W / 15.0V \Rightarrow 2.0A 30.0W / 20.0V \Rightarrow 1.5A 30.0W (30.0W Max)

Default Open Port: Classic Bluetooth

Port Description: After the device is powered on, Classic Bluetooth visibility (or pairing mode) is automatically enabled, providing Bluetooth pairing (or control) services. The Bluetooth service is disabled when the device is powered off.