



**WARRANTY CARD and
USER MANUAL**

**GAMING HEADPHONE
GS2**



e-Usermanual

IMPORTIR

PT. DORAN SUKSES INDONESIA

Jl. Lebak Jaya 2 Tengah No. 2, Surabaya

CUSTOMER SERVICE

 **081217393609**

 **jete.id**  **jeteindonesia**

 **jeteindonesia**  **jeteindonesia**

JETEX

USER MANUAL

GAMING HEADPHONE GS2



Please read the instructions carefully
before using the product.

Introduction Product :

Thank you for purchasing JETE product for optimal and safe performance, expected to read the instructions well before running this product

Content Package :




GS2



Adapter Cable
Audio 2in1



User
Manual



Greeting
Card

Description Structure Product :



1. Headband

2. Ear pad


3. Voice Control Volume

4. LED Light

5. Microphone

6. Splitter Cable

How to Use :



- Headsets can be used on 3.5mm jack audio like laptops and phones. JETEX-GS2 can be used on mobile phones using a splitter cable to optimize audio and microphone sound.
- When using headsets make sure the headset volume is active.
- Omnidirectional microphone, to easily adjust the user's face shape.

Spesification :

Model	: Gs2
Driver Unit	: 40 mm
Type Jack	: 3.5 mm
Impedance	: $16\Omega \pm 10\%$
Sensitivity	: $89\text{dB} \pm 3\text{dB}$ (@1KHz)
Frequency	: 20Hz-20KHz
Microphone	: $\varnothing 6.0 \times 2.7\text{mm}$
Current	: $\leq 100\text{mA}$
Speaker size	: 40mm
cable length	: 1.8 M
LED voltage	: $\text{DC}5\text{V} \pm 5\%$
Microphone Inpedance	: $\leq 2,2 \text{ K}\Omega$
Microphone Sensitivity	: $-42\text{dB} \pm 3\text{dB}$
Cable Jack	: 3.5mm + USB

Tips :

Listening to music too long can cause discomfort, it is expected to use moderate volume if possible. Do not listen using high volume too long

Maintenance :

Please read the following recommendations before using JETE

- Avoid exposing the device to water vapor or humid places. This can affect the internal circuit.
- Do not use cleaning solutions to clean the device.
- Do not expose the device to extreme heat or cold, as this can damage the device or change certain plastic parts.
- Avoid exposing the device to sharp objects, as this can cause scratches and damage.
- Do not disassemble or modify the device.
- Do not drop the device, as this can damage the circuitry.
- Always store the device at room temperature.

How to Warranty Claim JETE Product :

1. All warranty claims can be made at the list of Authorized Outlets listed on the warranty card.
2. Buyers can come to an authorized Outlet or contact Customer Service +62812-1739-3609 if they want to exchange the product online.
3. All expedition shipping costs / product postage are borne by the buyer.
4. When claiming the warranty, the buyer is MANDATORY to show the completeness of the warranty:
 - A purchase receipt that clearly states the name of the outlet and the date of the transaction.
 - The product must still be within the specified warranty period.
 - Warranty card that has been filled out.
 - Box / Packing Product.
5. Please inform the constraints / product damage that occurs to our staff.
6. WARRANTY DOES NOT APPLY if USER DAMAGE is found, namely:
 - BROKEN, CRACKED, BURNED, DROPPED, MODIFIED BY YOURSELF, SUBMERGED IN WATER.
7. If there are problems during warranty claims or other questions, please contact Customer Service +62812-1739-3609

Terms and Conditions of Warranty :

1. This warranty is valid for 2 years for original JETE products.
2. This warranty is valid for the warranty period stated on the product packaging since the date of sale.
3. During the warranty period, the user is exempt from any replacement costs that may occur.
4. The user must show the warranty card and purchase receipt when applying for a warranty.
5. The warranty applies to functional damage:
 - Disfunction.
 - Audio not detected.
 - Indicator off.
 - Battery damage.
6. This warranty DOES NOT APPLY if:
 - PRODUCT IS BROKEN, CRACKED, BURNED, FALLEN,
 - MODIFIED YOURSELF, SOAKED IN WATER.
 - Supporting accessories such as: cables, adapters, etc.
 - Abnormal use, not stored properly, natural disasters, modified, or anything intentionally.
 - The product has been repaired by a third party.
 - The data is not filled in completely by the seller and buyer.
 - Damage caused by user error.
 - The product warranty period has expired.

**2 YEARS
WARRANTY**

NEW REPLACEMENT
FOR ANY FAULTS *T&C



Contact Us

JETE WARRANTY POINTS

