


Утюги бытовые электрические с паровозлажателем торговой марки «TEFAL», модели:
FV6814xx, FV6834xx, FV6845xx, FV6846xx, FV6847xx, FV6848xx, FV6849xx, FV8042xx, FV8043xx, FV8044xx, FV8062xx, FV8064xx, FV8066xx, FV8082xx, FV8086xx,
 где х – любая буква от А до Z либо цифра от 0 до 9, которая обозначает страну назначения

Изготовлено во Франции для "GROUPE SEB", France
 (Groupe SEB, 112 Chemin du Moulin Carpon 69130 Ecully, France)
 Групп SEB, 112 Шмэн дю Мулен Карпон 69130 Экули Франс (Франция)
 Официальный представитель, импортер - ЗАО "Группа СЕБ-Восток"
 Россия, 125171, г. Москва, Ленинградское ш., д. 16А, стр. 3, помещение XII, тел. +7-495-213-32-32

EAC



1.

www.tefal.com
www.calor.fr

2.

www.tefal.com  www.calor.fr



2.

www.tefal.com www.calor.fr

TURBO

max.

TURBO **1 sec.**

TURBO **1 sec.**

TURBO **1 sec.**

NO



!!!

The diagram illustrates the correct and incorrect ways to use the TEFAL Calor Steam Iron's Turbo function. It shows how to activate Turbo by turning the dial to 'max.' and pressing the Turbo button for 1 second. The correct usage involves holding the iron at a distance from the fabric, allowing steam to penetrate. Incorrect usage includes direct contact between the soleplate and the fabric, which can cause damage or burns. A warning symbol indicates that the iron should not be used directly on the fabric.



2.




* * FR Poussiez et maintenez pressé / EN Push and hold / DE Gedrückt halten / NL Duw en houd vast / ES Pulse y mantenga presionado / PT Prima e mantenha a pressão / IT Tenere premuto / DA Tryk og hold / NO Trykk og hold nede / SV Tryck in och håll ner / FI Paina ja pidä / TR Basın ve basılı tutun / EL Κρατήστε πατημένο / PL Pociągnąć i przytrzymać / CS Stiskněte a podržte / SK Stlačte a podržte / HU Nyomja meg, és tartsa lenyomva / SL Pritisnite in pridržite / RU Нажмите и удерживайте / UK Натисніть і тримайте / HR Pritisnite i držite pritisnutim / RO Apăsați și mențineți apăsat / ET Vajuta ja hoida all / LT Paspauskite ir laikykite nuspaude / LV Nospiest un turēt / BG Натиснете и задръжте / KO 누르고 있음 / BA Pritisnite i držite pritisnutim / RC 长按 / HK 按住不放 / VN Ấn và giữ / TH กดค้างไว้ / SR Pritisnite i držite pritisnuto / AR ضغط مع الاستمرار / FA فشار داده و نگه دارید





3.




3.



3.



3.



FR	Guide de l'utilisateur	RU	Руководство пользователя
EN	User's guide	UK	Посібник користувача
DE	Bedienungsanleitung	HR	Upute za uporabu
NL	Gebruiksaanwijzing	RO	Ghidul utilizatorului
ES	Guía del usuario	ET	Kasutusjuhend
PT	Guia del usuario	LT	Naudotojo vadovas
IT	Manuale d'uso	LV	Lietošanas pamācība
DA	Brugsvejledning	BG	Ръководство на потребителя
NO	Bruksanvisning	KO	사용자 가이드
SV	Användarhandbok	BA	Korisnička uputstva
FI	Käyttöopas	RC	使用指南
TR	Kullanım kılavuzu	HK	使用指南
EL	Οδηγός χρήσης	VN	Hướng dẫn dành cho người sử dụng
PL	Instrukcja obsługi	TH	คู่มือสำหรับผู้ใช้งาน
CS	Návod k použití	SR	Uputstvo za upotrebu
SK	Používateľská príručka	AR	دليل المستخدم
HU	Használati útmutató	FA	راهنمای کاربر
SL	Navodila za uporabnika		



FR Pour plus d'informations sur l'utilisation / EN For further usage information / DE Weitere Informationen zur Bedienung / NL Voor meer informatie over het gebruik / ES Para obtener más información sobre su uso / PT Para obter mais informações sobre a utilização / IT Per maggiori informazioni sull'utilizzo / DA Yderligere informationer vedrørende betjening / NO For mer informasjon om bruken / SV För mer information om användningen / FI Lisätietoja käyttöä varten / TR Kullanım hakkında daha fazla bilgi için / EL Για περισσότερες πληροφορίες σχετικά με τη χρήση / PL Więcej informacji na temat korzystania z urządzenia / CS Pro více informací o použití / SK Pre ďalšie informácie o používaní / HU A használatra vonatkozó további információk / SL Več informacij o uporabi / RU Для получения более подробной информации об эксплуатации / UK Для отримання детальнішої інформації щодо експлуатації / HR Za više informacija o upotrebi / RO Pentru mai multe informații privind utilizarea / ET Täiendava teabe saamiseks kasutamise kohta / LT Daugiau informacijos apie naudojimą / LV Lai iegūtu vairāk informācijas par lietošanu / BG За още информация относно употребата / KO 더 자세한 사용 정보: / BA Za više informacija o upotrebi: / RC 更多关于使用的信息: / HK 更多關於使用的資訊: / VN Để biết thêm thông tin về cách sử dụng: / TH สำหรับข้อมูลเพิ่มเติม: / SR Za dodatne informacije o korišćenju: / AR برای کسب اطلاعات بیشتر برای استفاده / FA للمزيد من المعلومات عن الاستعمال

www.tefal.com
www.calor.fr

PUREGLISS