



1 检查清单

- 物品清单**
- LED灯泡 ×3
 - 控制盒 ×1
 - 网线 ×1
 - 电源适配器 ×1
 - USB接口电源线 ×1

注意：请自备无线路由器与智能手机，包装内不包含无线路由器和智能手机设备。

2 安装步骤

A. 安装控制盒

1. 将网线插入控制盒背部的接口，另一端接入家用无线路由器LAN口；
2. 将电源线接入控制盒电源接口，另一端插入电源适配器并接入电源插座。

注意：控制盒启动的时候指示灯会闪烁，启动完后常亮。

通过网线连接
无线路由器



通过USB电源线和
适配器连接电源

B. 安装灯泡

将灯泡拧入灯座，然后打开墙上的电源开关。

1. 请注意不要在密闭空间使用，以防止无法正常散热影响灯泡使用寿命和带来危险。
2. 长时间使用请勿用手触摸，以防止烫伤。



C. 连接应用

下载安装移动端应用，搜索盒子并进行控制。

注意：1. 确保移动终端和控制盒连接到同一Wi-Fi设备上。

2. 最多允许两部智能手机同时进行本地控制，远程控制限制为十部。

3 应用下载

扫描二维码，下载并安装应用。





iOS



Android

了解更多App信息
<http://www.yeelight.com>



1 CHECK

PACKING LIST

- LED bulb ×3
- Control Box ×1
- Network cable ×1
- Power adapter ×1
- USB power cable ×1


Note: You should have one Wi-Fi Router and on smart phone that can install Yeelight's APP.

2 SETUP

A. Control box

1. Connect box to a LAN port using network cable.
2. Plug USB power cable into control box, then connect the other end to power adapter, then plug adapter into socket to power it up.

Note: A blinking LED shows during boot up, then when box is ready the LED indicator changes to a continuous light.



B. Bulbs

Screw in the bulbs, then turn on the light.

1. Don't setup bulbs in closed space, there must be a good condition to ventilating the bulbs.
2. Be careful of the hot bulbs after long time run



C. Connect with APP

Download mobile App, search for Control Box to colorize your life.

Note: 1. Make sure the control box and your mobile are in the same network.

2. Locally, at most 2 mobile phones can control synchronously; Remotely, limitation is set to 10.

QR Code

Scan the QR code to download APPs.

3 MOBILE APP



iOS



Android

More APP information
http://www.yeelight.com