



Original	Recharge
 Power	 Power
 Tv/AV	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 +  Shift + Guide
 Recall	 PRE-CH Pre Ch
 P.Mode	 +  Shift + Format
 S.Mode	 +  Shift + Dual
 Nicam	 OPT Options

Original	Recharge
 Sleep	 Sleep
 Edit	 Smart
 Info	 Info
 Mute	 Mute
 Menu	 Menu
 Still	 Media
 EPG	 Guide
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 CH+	 Ch +



