


INSTRUCTION MANUAL




KOEHOGR K220 Video Baby Monitor
with 4.3" LCD Screen and Two Cameras

Please read the following instructions and warnings carefully
Keep this instruction manual for future.
For technical support see FAQ page.
For adult use only.

Get to know us at: www.koehog.com

FEATURES & COMPONENTS

Camera:



1. Power Indicator

2. Lens

3. Nighttime LEDs


4. Microphone

5. Temperature Sensor
6. Power On / Off Switch

7. Speaker

8. DC Jack

9. Wall Mounting Hole



1. LED*

2. Microphone

3. Video On / Off

4. Menu

5. Volume Up

6. Volume Down



7. Talk Back / Zoom

8. DC Jack


9. Battery Compartment

10. Speaker

11. Kickstand



Adapters:



WARNING

THIS PRODUCT CAN NOT SUBSTITUE PARENT’S SUPERVISION ON YOUR CHILD.

- Store this product out of the reach of babies (at least 3 feet (0.9 m) away from the crib). A strap wound around baby’s neck may result in asphyxiation. Use safety clip to clamp the power cord and keep it out of baby’s reach. Do not use other extension cords. Only use the power adapter provided.
- Do not touch the exposed part if the adapter is connected with power.
- Test regularly before initial use or when change the position of camera.
- Avoid placing the product in humid place or contacting with liquid. (such as bathtub, sink, etc.)
- Do not apply heat to the product.(such as stoves, radiators, etc.)
- Using the product in ventilated place. Avoid placing it on sofas, cushions, beds or other places which may block ventilation.
- The product only can be operated by adult. Do not allow baby to play with it. Tiny accessories are contained, please be careful when unpack and install it.

BATTERY WARNING

- Only use the recommended rechargeable battery. Please contact with us if you need to change it.
- For contact list, please refer to the last page of the instruction.
- Please clean the battery compartment before using.
- Avoid short circuit at power supply terminal.
- Remove the battery when you are not using it or when running out of power.
- Keep battery away from children.
- Dispose the empty battery properly.



WARNING

Asphyxiation Danger: Store this product out of the reach of babies (at least 3 feet away from the crib). A strap wound around baby’s neck may result in asphyxiation. Use safety clip to clamp the power cord and keep it out of baby’s reach. Do not use other extension cords. Only use the power adapter provided.



SETUP & USE

Please charge the battery for at least 8 hours before using the product.

Step 1: Test reception first, put camera in a suitable place that will provide you the best view of your baby in the crib (Note: Do not hang up the camera firmly until initial installation test is completed). Plug adapter into wall outlet and turn on the camera.

Step 2: Turn on monitor by pressing and holding Power / Menu button for 5 seconds until “axvue” shows up, then video will show up on the screen immediately. If video does not show up, please refer to “TO PAIR MONITOR AND CAMERA (ADD CAMERA)” at next page. If video shows up, the initial installation test is completed, then you can set up the camera according to the instruction below.

Set Up Camera: Place camera on a flat surface, such as wardrobe or shelf (Figure 1). Or hang it on the wall (Figure 2). No matter wherever to place the camera, please make sure to keep it away from the crib for at least 3 feet and all power cords should be placed behind the camera properly. Then adjust the angle of camera lens until the entire crib shows up on the display, or adjust it to the best angle that you think to watch your baby.



TO USE PLUGGED-IN MODE

Step 1: Place the monitor display in living room, bedroom or any place you want to watch your baby. Use adapter to connect camera with electrical outlet.

Step 2: Turn on monitor by pressing POWER/MENU button for 5 seconds until axvue logo or video shows up on the screen.

Step 3: Press VIDEO ON/OFF button to turn off the video if you only need to hear the voice.

Step 4: Turn off the monitor completely by pressing and holding POWER/MENU button for 5 seconds.

TO USE PORTABLE / BATTERY MODE

Please charge the battery for 6~8 hours before using the product.

Step 1: Charge the battery for at least 8 hours before using portable / battery mode.

Step 2: Make sure the adapter is plugged into camera.

Step 3: The battery life can be up to 10 hours if it is fully charged.


Battery life will be shortened if recharging it continuously. Unplug the power adapter when you are not using it for a long time.

TO PAIR MONITOR AND CAMERA (ADD CAMERA)

The monitor and camera are paired before shipment. If it is unpaired for some reason, please refer to the following steps:

Step 1: Make sure the camera and monitor are in the same place.

Step 2:



Make sure the power adapter is plugged into camera and turn on the camera by pressing Power On/Off Switch “CODE” button for 5 seconds.

Step 3:



Turn on monitor by pressing and holding VIDEO button for 5 seconds.

