

PRIMO[®]
hTRIO[™]



MULTI-PURPOSE
BEVERAGE DISPENSER
B380K

FEATURES



- STORAGE COMPARTMENT** – Removable tray keeps single-serve brewer pods organized. (Pods sold separately.)
- CONVENIENCE SWITCHES** – On/off switches for heating, cooling and nightlight are located on the back of the dispenser.
- BREW CONTROLS** for single-serve beverage dispensing – Select 6, 8 or 10 ounce serving size.
- EMPTY BOTTLE LIGHT** – Blinks red when the bottle is empty and needs to be replaced.
- HEATING LIGHT** – Flashes when the water is heating. Stops flashing when water is fully heated.
- BREWER CUP DRAWER** – Brews single-serve beverage pods. Press gray button to remove drawer. CAUTION: Keep fingers clear of sharp needle inside drawer.
- COLD WATER PADDLE CONTROL** – Press drinking glass or container against the paddle to dispense. Release to stop.
- HOT WATER PADDLE CONTROL** with child-resistant safety feature – Push red button and press mug or container against the paddle to dispense. Release to stop.
- PROBE ASSEMBLY** – Probe pumps water from the bottle into the hot and cold reservoirs.
- PROBE HANGER** – Rest probe assembly on the hanger (located inside the cabinet door) to keep it clean while replacing bottles.
- DRIP TRAY** with Full Indicator – Removable and dishwasher-safe. Red indicator rises when it's time to empty.
- WATER BOTTLE** – Not included. Uses 3 and 5-gallon bottles. Visit PrimoWater.com to find Primo® water at the store nearest you.

WARNINGS & SAFETY PRECAUTIONS

To reduce risk of injury and property damage, user must read this entire guide before assembling, installing & operating dispenser.

Failure to execute the instructions in this manual can cause personal injury or property damage. Models that heat water dispense at very high temperatures. Failure to use properly can cause personal injury.

When operating this dispenser, always exercise basic safety precautions, including the following:

- Prior to use, this dispenser must be properly assembled and installed in accordance with this manual.
- This dispenser is intended for water dispensing only. Do NOT use other liquids. Do NOT use for other purposes. Never use any liquid in the dispenser other than known and microbiologically safe bottled water.
- For indoor use only. Keep water dispenser in a dry place away from direct sunlight. Do NOT use outdoors.

- Install and use only on a hard, flat and level surface.
- Do NOT place dispenser into an enclosed space or cabinet.
- Do NOT operate dispenser in the presence of explosive fumes.
- Position back of dispenser no closer than 4 inches from wall and permit free airflow between wall and dispenser. There must be at least 4 inches clearance on the sides of the dispenser to permit airflow.
- The dispenser is intended to be plugged into a ground fault interrupting receptacle.
- Do not use an extension cord with your water dispenser.
- Always grasp plug and pull straight out from outlet. Never unplug by pulling on power cord.
- Do NOT use dispenser if cord becomes frayed or otherwise damaged.
- To protect against electric shock, do NOT immerse cord, plug, or any other part of dispenser in water or other liquids.
- Ensure dispenser is unplugged prior to cleaning.
- Never allow children to dispense hot water without proper and direct supervision. Unplug unit to prevent unsupervised use by children.
- Do not dispense hot water if water bottle is empty.
- Please contact us at 866-429-7566 for troubleshooting assistance.

QUICK START GUIDE


- Place the dispenser on the floor in the desired location in your home. Product is intended for indoor use only. [Note: Do NOT plug power cord into wall outlet until instructed.]




- Position dispenser so the back is at least 4 inches from wall and there are at least 4 inches of clearance on both sides.




- Slide drip tray into place.




- Slide brewer cup drawer into the slot until it clicks. CAUTION: Keep fingers away from the inside of the tray as the needle is very sharp.



- Clean probe with a damp cloth and dish soap. (Visit PrimoWater.com for detailed cleaning instructions.) Place probe assembly on hanger inside door to keep it clean.



- Grab a bottle of Primo® water (sold separately) and fully remove the cap. Insert probe assembly into bottle. Press firmly to secure assembly over bottle opening. For 3-gallon bottles, squeeze the tabs on the top of the probe assembly to separate the probe cap from the collar and press the collar securely over the bottle opening.




- Slide bottle inside the cabinet and close cabinet door. [Note: Water will not pump from bottle unless door is fully closed.]



- Plug dispenser into a ground fault circuit interrupting (GFCI) outlet. You will hear the dispenser begin to pump water to fill the internal hot and cold reservoirs.




- Turn on desired functions by flipping the switches on the back of the dispenser to the ON position. Blue – nightlight
Green – chills water
Red – heats water



- Once the dispenser has stopped filling the internal reservoirs, dispense and dispose at least 1 quart (approximately 2 pint glasses) of water from both the hot and cold spouts.



- Your water will be ready to dispense fully chilled in approximately 1 hour or piping – hot in approximately 12 minutes.



- Register your dispenser at PrimoWater.com to activate your warranty, which runs for 1 year from date of purchase.

Primo® Pre-Filled Exchange Water or Self-Service Refill Water from Primo® & Glacier® (sold separately)



Available at thousands of locations nationwide. Learn more at PrimoWater.com/locations.

CARACTERÍSTICAS

- **COMPARTIMIENTO DE ALMACENAJE** – Bandejas desinstalables para mantener organizados las capsulas individuales (las capsulas se venden por separado).
- **INTERRUPTORES CONVENIENTES** – Los interruptores de encendido y apagado para calentar, enfriar y luz nocturna están ubicados en la parte trasera del dispensador.
- **CONTROLES DE FILTRADO** para dispensar bebidas individuales – Seleccione entre 6, 8 o 10 onzas.
- **LUZ DE BOTELLÓN VACÍO** – Luz roja parpadeante indica que el botellón está vacío y necesita reemplazarse.
- **LUZ DE CALENTAMIENTO** – Parpadea cuando el agua está calentándose. Deja de parpadear cuando el agua terminó de calentarse.
- **RECEPTÁCULO PARA VASITOS FILTRANTES INDIVIDUALES** – Para filtrar capsulas individuales. Presione el botón gris para retirar el receptáculo. PRECAUCIÓN: Mantenga los dedos lejos de la aguja filosa dentro del receptáculo.
- **PALETA PARA AGUA FRÍA** – Presione el vaso o contenedor contra la paleta para dispensar agua. Deje de presionar para parar.
- **PALETA PARA AGUA CALIENTE** con mecanismo de seguridad para niños - Presione el botón rojo y empuje el tazón o contenedor contra la paleta para dispensar. Deje de presionar para parar.
- **ENSAMBLE DEL TUBO SURTIDOR** – El tubo surtidor bombea agua desde el botellón hacia los tanques de agua caliente y fría.
- **COLGADOR DEL TUBO SURTIDOR** – Coloque el tubo surtidor en el colgador (ubicado dentro de la puerta del gabinete) para mantenerlo limpio cuando cambie el botellón.
- **BANDEJA DE GOTEO CON INDICADOR DE QUE ESTÁ LLENA** Desinstalable y puede lavarse en máquina lavaplatos. El indicador rojo se eleva cuando es tiempo de vaciarlo.
- **BOTELLÓN DE AGUA** – No se incluye. Usa botellones de 3 y 5 galones. Visite PrimoWater.com para encontrar agua Primo® en la tienda más cercana a usted.







ADVERTENCIAS Y PRECAUCIONES DE SEGURIDAD

Para reducir el riesgo de lesiones y daños materiales, el usuario debe leer completamente esta guía antes en ensamblar, instalar y operar el dispensador. El no seguir las instrucciones de este manual puede causar lesiones personales o daños materiales. Los modelos que calientan agua la dispensan a temperaturas muy altas. El uso inapropiado puede causar lesiones personales. Al operar este dispensador, siempre siga las precauciones básicas de seguridad, entre las cuales están las siguientes:

- Antes de usarlo, este dispensador debe estar ensamblado e instalado correctamente según las instrucciones de este manual.
- Este dispensador está diseñado para dispensar agua solamente. NO lo use con otros líquidos. NO lo use para otros propósitos. Nunca use ningún otro líquido en este dispensador que no sea agua embotellada conocida y microbiológicamente segura.
- Solo debe usarse en interiores. Mantenga el dispensador de agua en un lugar seco y lejos de la luz solar directa. NO lo use en exteriores.
- Instalelo y úselo solamente sobre una superficie dura, plana y nivelada.
- NO coloque el dispensador en un espacio cerrado ni gabinete.
- NO opere el dispensador en presencia de vapores explosivos.
- Coloque la parte trasera del dispensador a una distancia de por lo menos 4 pulgadas (10 cm) de la pared y permita que circule el aire entre la pared y el dispensador. Debe haber por lo menos un espacio de 4 pulgadas a cada lado del dispensador para permitir el flujo de aire.
- El dispensador está diseñado para enchufarse en un enchufe con circuito de falla a tierra.
- No use una extensión eléctrica con el dispensador de agua.
- Siempre jale el enchufe para desconectarlo del tomacorriente. Nunca desenchufe jalando el cordón eléctrico.
- NO use el dispensador si el cordón eléctrico está gastado o dañado.
- Para protegerse contra choque eléctrico, NO sumerja el cordón, el enchufe ni ninguna otra parte del dispensador en agua u otros líquidos.
- Asegúrese de que el dispensador esté desenchufado antes de limpiarlo.
- Nunca permita que los niños dispensen agua caliente sin la adecuada y directa supervisión. Desenchufe la unidad para evitar que los niños la usen sin supervisión.
- No dispense agua caliente si el botellón está vacío.
- Si vase llamarnos al 866-429-7566 para obtener ayuda con la resolución de problemas.

GUÍA PARA INICIO RÁPIDO

1. Coloque el dispensador en el piso del lugar seleccionado en su casa. [Nota: NO enchufe el cordón eléctrico en el tomacorriente de la pared hasta que se le indique].
2. Coloque el dispensador de manera que la parte trasera esté por lo menos a 4 pulgadas de la pared y haya por lo menos 4 pulgadas de espacio libre en ambos lados.
3. Deslice la bandeja de goteo en su lugar.
4. Deslice el receptáculo para vasitos filtrantes dentro de la ranura hasta que haga clic. PRECAUCIÓN: Mantenga los dedos lejos del interior del receptáculo ya que la aguja es muy filosa.
5. Limpie el tubo surtidor con un paño empapado y jabón para platos. (Visite PrimoWater.com para obtener instrucciones detalladas de limpieza.) Coloque el tubo surtidor en el colgador del interior de la puerta para mantenerlo limpio.
6. Tome un botellón de agua Primo® (se vende separadamente) y retire completamente la tapa. Inserte el tubo surtidor dentro del botellón. Presione firmemente para asegurar el tubo surtidor sobre la abertura del botellón. Para botellones de 3 galones, apriete las lengüetas situadas en la parte superior del tubo surtidor para separar la tapa del tubo del collarín y presione el collarín con firmeza sobre la abertura del botellón



12. Registre su dispensador en PrimoWater.com para activar su garantía de un año a partir de la fecha de compra.

Agua Primo® del programa de descuento a cambio de botella o de autoserivicio de resurtido de agua de Primo® & Glacier® (de venta por separado)



Disponible en miles de ubicaciones en todo el país. Conozca más en PrimoWater.com/locations.

DISPENSADOR MULTIOSOS
DE BEBIDAS
B380K



PRIMO[®]
h t r i o[™]