Lilitab Pro Desk Mount

Shipment Content:

- 1 x Countertop Basic Mount
- 1 x Compact Metal Base
- 4 x Compact Base Screws
- 1 x Phillips Screwdriver
- 1x Key

Quick Setup:

1. To open the faceplate, squeeze & hold the 2 buttons at the back of the faceplate while sliding the bezel upwards (opposite to the RFID reader).



2. Connect the NFC reader to the USB charging cable, switch the toggle to Bluetooth and place it in the Lilitab case.



- **3.** Connect the *iPad* to the **lightning charging cable found inside the Lilitab case** and then place the iPad in the Lilitab case.
- **4.** Secure the *iPad* into the case by sliding in the **faceplate** towards the NFC reader and clicking it into place. *Verify it is properly locked*.



5. Please follow the **NFC reader** connection steps from your registration software provider. *Do not add Bluetooth device right away via iPad settings.*





6. Please follow the NFC reader connection steps from your registration software provider. Do not add Bluetooth device right away via iPad settings.



- Place the completed faceplate onto the Mag Dock of Lilitab stand. It should sit tight and secure.
- **8.** With the provided key, lock the case on to the desk stand. *Keep the key secure for removal.*
- **9.** Adjust the viewing position by tilting the **iPad** up and down.



10. Once the iPad is set up and attached to the Lilitab floor stand, your device will be ready for use.



Setup Video Guide: Scan this QR code with your phone camera for video.





Contact our Support Team: www.choose2rent.com/help +1 (800) 622-6484 Ext. 3 (USA)

RENTAL EQUIPMENT SETUP GUIDE

Lilitab Pro Desk Mount

Troubleshooting:

What if...

my NFC reader does not light up?	 Inspect the cable at both the power cable and reader ends. Rotate the iPad's faceplate to see if it charges in various
	orientations. 3. Ensure that the reader is powered on.
my iPad is not charging?	 Inspect the cable at both the power cable and iPad ends. Rotate the iPad's faceplate to see if it charges in various orientations.
the viewing position won't remain fixed?	Use the supplied Allen wrench to adjust the viewing angle according to your preference.

