





Digital Guide

Here are the primary steps for installation of an Irrigreen Irrigation system. Scan QR Code above for detailed step-by-step digital installation guide.

## Prep + Layout

Verify you water source is:

- Pressure is between 40-80 PSI
- Flow rate is 8+ GPM
- No debris or sediment present
- Layout Zone and Head Location
  - Place each head at distance according to pressure & flow rate

Check with local guidelines or trench to a minimum 12" depth

Trench, Run Water Line, Run Cabling

### Scan for Detailed Steps



Download Irrigreen App:

"Irrigreen 2" in Apple App Store

"Irrigreen Homeowner" in PlayStore

### Scan for Detailed Steps



## Installation

Connections, Cabling, and Backfill

- Connect heads and cables.
  i1 + i2 terminals and commons
  Connect in trenches before backfilling soil
- Check connections via app's Test & Detect
- Wire 3<sup>rd</sup> party components (if present)
- Assign heads to zones
- Backfill trenches

# System Setup

Calibrating, Mapping, and Schedules

- Calibrate every head (required before mapping)
- Map every Zone's shape
- Program schedules
- Enable AutoWater

#### Scan for Detailed Steps





**Web**: support.irrigreen.com **Support**: service@irrigreen.com **Phone**: 1-855-288-6426

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference.
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by Irrigreen could void the user's authority to operate the equipment. To satisfy RF exposure requirements, the Irrigreen Sprinkler must operate with a separation distance of at least 20 cm from all persons