

210\*140

**anko**

## Specification:

Multi Colour LED

50x50mm Amorphous Solar Panel

1x AAA Ni-Cd rechargeable battery 1.2V, 300mAh

Static and Flashing function

## IMPORTANT:

- Charge battery for at least 8 hours before first use.
- The solar light panel **MUST** be placed in a well-lit location for maximum sunlight. Anything that shades the panel will affect the brightness and lighting duration.
- Put the switch on the "OFF" position when not in use or in storage.
- Use a damp cloth to clean it when there is a buildup of dust and/or dirt on the surface of the solar panel.

## Battery Replacement

The battery is non-replaceable. **DO NOT** attempt to replace it.

## Bulb Changing


The light set is constructed with non-replaceable bulbs. **DO NOT** attempt to replace any of the bulbs in the light set.

WARNING: FOR DECORATION ONLY. THIS IS NOT A TOY. DO NOT ALLOW CHILDREN TO PLAY WITH AND HANDLE LIGHT SETS.

# SOLAR POWERED 4 STAR STAKE LIGHTS

### Instructions:

- › Assemble the solar panel as shown in the picture.  
A-Solar Panel B- Plastic Cylinder C-Plastic Spike
- › Attach part B on to the back of solar panel A, then attach C to B by pressing firmly.
- › Switch F means Flash, S means Steady. Choose either of them to turn the light on. You will only need to do this once, as the solar panel will turn the lights on and off automatically.
- › Place entire unit in a sunny position where there is soft ground to enable the spike to be pushed in easily.



**Keycode: 42778660**