

You must read this manual carefully before using the hair dryer. If you haven't read the instructions carefully, there will be any problems during use, Our company will not be responsible!


The hair dryer used a unique intelligent temperature control and airflow multiplier technology to quickly dry hair while preventing damage to the Product hair caused by excessive temperature. 3 types of air nozzles are available to meet your different styling needs. Take care of your hair and create a different beauty.

Product Parameters

Product Name	Hair Dryer F350				
Product Name					
Parameters	Numerical Value	Unit	Exhaust Port		
Nega⊠ve ion amount	3	million	One-Bu⊠on –		
Sound at maximum air volume	83.4	Decibel	Cool/ Hot Switch	* * * * * * * * * * * * * * * * * * *	Po Ho
Temperature at cold air gear (about)	35	С		30 cm	a t
1st gear temperature (about)	47	C			
2nd gear temperature (about)	65	C			
Voltage	110 - 125	V			

Diffuser curl nozzle Dry hair quickly and disperse heat evenly diffuser-focused airflow to make natural curls and waves of hair

Styling nozzle





UNLOCK

Instructions for Use Dry hair only 1.Connect the power supply and open the switch on the

2.Choose the air speed you want

 Gentle warm wind keeps your hair hydrated and prevents it from drying out

II. Strong wind for quick drying of hair

3. Hold the hair dryer, keep a distance of about 10 cm from the hair, and move back and forth at a constant





Malfunction Make a hairstyle when you dry your hair


- Connect the power supply and open the switch on the handle.
- Step 1, Choose the nozzle that suits your desired hairstyle:

step2, Choose the wind speed you want:

Distance using nozzle

Choose the type of wind and nozzle.





6.There are noise and burnt smel

I. Gentle warm air keeps your hair hydrated and prevents it from

After the hairstyle is designed, cool the hair with cold wind to m

Push the switch to o' and unplug the power cord after using.

Abnormal Situation Handling

strong wind for quick drying of hair.

Can't start or interrupt con ∑nuously

The power cord is disconnected.

The power cord is not plugged in well.

Poor contact of the replace the motor.

Ask the professional to replace the power cord

Send the seller or the company to repair or get a replacement

The wind is obviously less, and the temperature rises sharply.

the style more lasting.

Plug in the socket

The air inlet is blocked

Air inlet blockage

Diode damage.

The motor is not normal

The motor is not normal

Please clean the air inlet regularly.


Please clean the air inlet regularly.

Send it to the seller or the company to overhaul.

2.Over-heat

- To reduce the risk of burns, fire, electric shock or
- injury to persons:
- 7.There is abnormal noise when shaking or sharp fric⊠on when star □
 - 1. An appliance should never be left unattended when it's plugged in
 - 2. Close supervision is necessary when this appliance is used by, on,
 - or near children or individuals with certain disabilities or special
 - 3. Use this appliance only for its intended use as described in this
 - manual. Do not use attachments not recommended by manufacturer.

- is not working properly, if it has been dropped or damaged, or if it
- has been dropped into water. 2. Use a dry cloth to remove hair and dust from the outlet eve
 - 5. Keep the cord away from heated surfaces. Do not wrap the cord
- Make sure it is dry before using or storing the hair drye
- 5. Do not wrap the power cord around the product during st



the product's function. It can even block the product, which damage the product and bring danger in serious cases.

- Never use while sleeping.
- 8. Never drop or insert any object into any of the appliance's don't know how to deal with it.

9. Do not use outdoors or operate where aerosol (spray) products

- are being used, or where oxygen is being administered.
- Do not direct hot air toward eyes or other heat-sensitive areas.
 - 11. Do not place appliance on any surface while it is operating

While using the appliance, keep your hair out of it–keep your ha

device built into the plug. This device is designed to make the unit Do not use in area with 220/240 volt electrical systems; use inoperable under some abnormal conditions, such as accidental

only with110/120 volt electrical systems. immersion in water. The ALCI safety device is equipped with a test 14. Do not use an extension cord or a voltage converter with the button so that its operation can be checked. This unit should be te-

4. Never operate this appliance if it has a damaged cord or plug, if it

- 1. This product must not be stained with water. Also, remember not use this product with wet hands.
- around the appliance.
- 6. Never block the air openings of the appliance or place it on a soft
- surface, such as a bed or couch, where the air openings may be

blocked. Keep the air openings free of lint, hair, dust etc. This means

This hair dryer is provided with an appliance leakage circ

sted before each use to confirm that the safety device is operational

1. Should the ALCI safety device trip (i.e., reset button pops out) during use, press the reset button. Never operate this appliance if and human health. To protect our planet, please strictly follow the local has been dropped inwater. Garbage Recycling and Environmental Protection Act and place if

defeat this safety feature.

GROUND

2. The dryer is designed to work on ordinary household current on dedicated garbage collection bin or recycling bin. Please conta community manager or the relevant government department if 125 volts A.C., 60 Hz. It is not intended for commercial us

other). As a safety feature, this plug will fit in a polarized outlet only

3. This appliance is equipped with an automatic thermal limite

Why do you need a GFCI? which will cycle off when overheated and come back on when coo

Electricity and water don't mix. If your hair dryer falls in water while before restarting.

> one way. If the plug does not fit fully in the outlet, reverse the plug A regular fuse or circuit breaker won't protect you under these circ-If it still does not fit, contact a qualified electrician. Do not attempt to



THIS MESSAGE ABOUT

To test: After plugging in your hair dryer:

- 1. Press the reset button on the ALCI device.
- 2. Press the test button. The reset button will pop out. This verifies that the safety device is operating properly. 2. Be sure to keep the power off when the product is not in us
- Press the reset button to reactivate your ALCI safety device.
 - Your hair dryer is now ready for use.

Note: This unit may automatically trip when unplugged. If so, the If you must use your hair dryer in the unit must be reset after it is plugged in. bathroom, install a GFCI* now!

> a portable unit that plugs into the electrical outlet or a permanent unit installed by your electrician. The National Electrical Code no requires GFCI's in bathrooms, garages, and outdoor outlets of al

ed down. If the unit cycles off, unplug the cord for several minutes

t's plugged in, the electric shock can kill you- even if the switch is 4. This appliance has a polarized plug (one blade is wider than the

umstances. A GFCI offers you greater protection



Your local electrician can help you decide which type is best for

A GFCI can save your life!

Compared to that, the price is small!

CAN SAVE A LIFE! current leak by stopping the electricity flow.



4. The power cord's temperature is too high or the plug's temperature is

Power cord disconnection is poor

Motor carbon brush wear abrasion.

Internal accessories are not normal.

Internal support is broken and damaged

Cleaning and Maintenance

1. Keep the power off when the product is not in use

Motor damage.

Please Stop using

Please Contact us.

Please Stop using.

Please Contact us

Please Stop using.

Please Contact us

Ask the professional to replace the power cord.

5.Does not work or does not respond a er the motor starts.vv

3. Regularly clean it and keep the product clean.

*GFCI is a sensitive device that reacts immediately to a small electric

a 100% satisfactory response.

Ŋ About After-sales Service

provides you with THE BEST QUALITY, BEST PRICE&BEST

about the product, or it is damaged, missing parts. Please

SERVICE. After receiving the package, if you have any concerns

contact our after-sales customer service via your order : Or con

tact our Dealer After-sales Customer Service Center (Contact

way can be found on the Dealer Profile). Our dealers will give you

Thanks for choosing Our Hair dryer. This manual





