

FIREFIGHT PRO 23



RGB 60% MECHANICAL GAMING KEYBOARD

INSTRUCTION MANUAL

ADXMK0823



Contents

Safety Warnings.....	3	User Interface - Customise	11
Unpacking	4	User Interface - Light	12
System Requirements	4	User Interface - Macro	13
Function Keys.....	5	User Interface - Light Effect	14
Volume Keys.....	5	Hints and Tips.....	15
Arrow Keys	6	Specifications.....	15
Backlight Effect.....	7		
Customising the Backlight Effect	8		
Software Installation.....	9		
User Interface.....	10		

Safety Warnings

- Read all the instructions carefully before using the unit and keep them for future reference.
- Retain the manual. If you pass the unit onto a third party, make sure to include this manual.
- Do not disassemble the keyboard or remove any parts.
- Do not immerse the keyboard in water or any liquid.
- Do not use the keyboard close to heat sources or expose to high temperatures.
- Do not use the keyboard where strong electromagnetic waves are present. Strong electromagnetic waves will cause damage to the keyboard.
- Keep the keyboard away from direct sunlight, moisture, dirt or abrasive chemical products (cleaning products etc).

Thank you for purchasing your new product.


We recommend that you spend some time reading this instruction manual in order that you fully understand all the operational features it offers. You will also find some hints and tips to help you resolve any issues.

Read all the safety instructions carefully before use and keep this instruction manual for future reference.

Unpacking

Remove all items from the packaging. Retain the packaging. If you dispose of it please do so according to local regulations.

The following items are included:



Gaming keyboard

System Requirements

Operating Systems: Microsoft® Windows® 8 / 10 / 11

Hardware: 1 available USB port

Function Keys

To access **Esc**, **F1-F12**, **Delete**, press the **Fn** Key and the desired key together.



Volume Keys

To access volume function, press the **Fn** Key and the desired key together.




	Decrease the Volume
	Increase the Volume
	Mute sound

Arrow Keys

Press the **Fn** Key and **W** Button repeatedly to switch on/off **Arrow Keys** function.

After the **Arrow Keys** function is switched on, press **W / A / S / D** for your desired arrow direction.




W ▲	Up
S ▼	Down
A ◀	Left
D ▶	Right

Backlight Effect

To access these functions, press the **Fn** Key and the desired key together.


	Adjust the backlight flashing sequence level.
	Switch the backlight on/off.
	Select different backlight effects. (18 modes / 1 customised mode)
	Adjust the backlight brightness.
Spacebar	Change the backlight colour.



Customising the Backlight Effect

You may customise the backlight for each keypress.

1. Press **Fn** +  repeatedly to select customise backlight mode. Keypress **WASD** will light up as the first time.
2. Press and hold **Fn** +  to enter backlight setting mode. **CAPS** and **WIN** keypresses will start flashing.
3. Press the keypress(s) repeatedly to choose the colour you wish (8 colours + 1 colourless).
4. Press and hold **Fn** +  when done. **CAPS** and **WIN** keypresses will stop flashing.



To reset customised backlight effect to default setting, press and hold **Fn** +  until all backlights start lighting in succession.

Software Installation

1. Plug the unit into the USB port of your computer.
2. Download the latest gaming software from **<https://downloads.adxgaming.com>**
3. Run the software installer (**ADX HUB 2 Setup.exe**).
4. Follow the installation instruction to complete the installation.
5. Choose **ADX HUB 2.exe** from the desktop to start the software.



The software is not available for MAC OS.

User Interface

1. Choose **ADX HUB.exe** from the desktop to launch the software.
2. Select "**Keyboard**" and then "**ADXMK0823**" in the connected device menu to enter the interface.



User Interface - Customise

1. Select **Customise**, and then select your customised settings.
2. After settings, save your own preference in the **Profile** menu.
3. Select **"Apply"** to implement your settings, or **"Reset"** to reset all settings.




User Interface - Light

1. Select **Light** to enter the **Lighting Settings** menu.
2. Choose your preference among the below:
 - **Mode**
 - **Brightness**
 - **Speed**
 - **Color Mode**
3. Select "**Apply**" to implement your settings, or "**Reset**" to reset all settings.



User Interface - Macro

1. Select **Macro**, and then “+” to create a **New Macro Command**.
2. Press **Start Recording**.
3. After recording your input command, press **Stop Recording**.
4. You may edit your recorded commands on the right menu.
5. Select “**Apply**” to implement your settings, or “**Reset**” to reset all settings.



User Interface - Light Effect

If one more ADX gaming device is connected, you may synchronize their light effects.

1. Select **Light Effect**, and the devices you want to apply the light effect.
2. Select your preferred **Lighting Settings** (**Mode**, **Brightness** and **Speed**).
3. Select "**Apply**" to implement your settings.



To reset the setting of a particular device, select a connected device shown in the menu, and then select **Reset**.



Hints and Tips

- Make sure the USB plug is fully plugged into a USB port and the computer is on or try to use a different USB port.
- If the unit is not working properly, re-insert the USB plug into the USB port.

Specifications

Model	ADXMK0823
Dimensions (L × W × H)	293.6 × 103.7 × 42.3 mm
Net Weight	608 g

Features and specifications are subject to change without prior notice.



The symbol on the product or its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste for recycling, please contact your local authority, or where you purchased your product.

Windows is a registered trademark of Microsoft Corporation in the United States and other countries.

All trademarks are the property of their respective owners and all rights are acknowledged.

Currys Group Limited (co. no. 504877)
1 Portal Way, London, W3 6RS, UK

EU Representative

Currys Ireland Limited (259460)
3rd Floor Office Suite
Omni Park SC, Santry, Dublin 9, Republic of Ireland

IB-ADXMK0823-221102V2