


LEISURE 410

USER MANUAL

Please read this manual thoroughly before using and keep it for future reference.

PACKING LIST



LEISURE 410



Carrying Bag




Remote




User Manual


(Batteries Not Included)



AV Cable




HD Cable




Power Cable

NOTICE





Recommended




NOT Recommended




FUNCTION OVERVIEW




QUICK START



Plug the power cord into an outlet .




Take off the lens cover.




* Sold Separately


Connect your device to the projector correctly.




Press the **Power Button** to turn on the projector.




Select the correct input source to project your device.



Adjust the kickstand accordingly.



Adjust the keystone and focus ring to get the best image performance.




Press the **Power Button** twice to turn off the projector .

INPUT SOURCE


Press  on the projector or remote to enter the interface of Input Source.

A. Multimedia Connection




Input Source
ATV
VGA
HDMI
AV
USB/SD
 OK

B. HD Connection






Input Source
ATV
VGA
HDMI
AV
USB/SD
 OK

C. VGA Connection




Input Source
ATV
VGA
HDMI
AV
USB/SD
 OK

PROJECTOR CONNECTION



PROJECTION DISTANCE&SIZE



The recommended projection screen is around 90 inches with a distance of around 9.84ft. Ambient darkness will improve the clarity of the projected images.

SPECIFICATION

Display Technology	LCD	Light Source	LED
Resolution	Native 1280 x 720	Input Signal	420P, 720P, 1080P
Installation Type	Front/Rear/Ceiling	Aspect Ratio	4:3/16:9/Auto
Focus	Manual	Keystone	±15°
Speaker	2W/4ohm	Power Supply	AC 100-240V, 50/60Hz
Unit Dimension	575 x 320 x 450mm (22.6 x 12.6 x 17.7 inch)	Unit Net Weight	1.2kg(2.6lb)
Photo Format Supported	BMP/JPG/PNG	Audio Format Supported	MP3/WMA /M4A/AAC/WAV
Video Format Supported	MPG/MPE/VOB/TS/RM/RMVB/ AVI/MP4/DIV/MOV/MKV/ASF/FLV/ WMV/3GP/3G2	Ports	AV x 1/VGA x 1/USB x 1/HD x 1/ ATV x 1/Audio Out x 1/ Memory Card Slot x 1
Mounting Screw	1/4"	Number of Screw	Not included

TROUBLESHOOTING GUIDE

1. Blurry Image

- * Adjust focus ring/keystone.
- * Projector and screen/wall must be in effective distance.

2. Remote Unresponsive

- * Make sure remote points at IR receiver directly.
- * Do not cover IR receiver.
- * Try a new pair of batteries.

3. Mobile Connection

iOS: Genuine lightning to HDMI cable

Android: Micro USB to HDMI adapter/Type C to HDMI cable

4. Upside Down Images

Enter "Menu" on projector remote to flip the projection image.

CAUTION



The symbol indicates AC voltage



RECYCLING

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment.

This product can be used across EU member states.

VANKYO SUPPORT

North America support@ivankyo.com

United Kingdom support.uk@ivankyo.com



www.ivankyo.com



[@VankyoOfficial](https://www.facebook.com/VankyoOfficial)



[VANKYO](https://www.youtube.com/VANKYO)