



Installation guide - Spare parts and accessories

Solenoid valve - Spare part actuator kit NO


Type EV220S and EV220W

042R9048

042R9048




Total pcs.
= A,B,D,E




Total pcs. = C

A




Total pcs. = 2

B




Total pcs. = 1

C




Total pcs. = 1

D



Total pcs. = 1

E



Total pcs. = 1

