




L430S

- DE Contents
- FR Contenu
- NL Inhoud
- FI Sisältö
- OK Indhold
- IT Contenuto
- ES Contenido
- PT Conteúdo
- GR Περιεχόμενα
- SE Innehåll



x1




x2







x2








x2





- DE Component locations
- FR Emplacement des composants
- NL Componentlocaties
- FI Asemennuspaikan valinta
- OK Komponentplacering
- IT Posizionamento del dispositivo
- ES Ubicaciones de los componentes
- PT Posicionamento dos componentes
- GR Θέσεις στοιχείων
- SE Placering






- DE Battery install
- FR Installation des piles
- NL Batterij installeren
- FI Pariston asennus
- OK Isætning af batteri
- IT Installazione batteria
- ES Instalación de la batería
- PT Instalação da bateria
- GR Τοποθέτηση της μπαταρίας
- SE Installation av batteri






- DE Linking
- FR Liaison
- NL Koppelen
- FI Linkitys
- OK Tilslutning
- IT Collegamento
- ES Enlace
- PT Ligação
- GR Ζεύξη
- SE Länkning








- DE Installation
- FR Installation
- NL Installatie
- FI Asemus
- OK Installation
- IT Installazione
- ES Instalación
- PT Instalação
- GR Τοποθέτηση
- SE Installation









GB Walk test DE Funktionstest
FR Test de mise en route NL Looptest
FI Kävelytesti DK Gennemgangstest
IT Test intrusione ES test de paso
PT Teste de caminhada GR Δοκιμή
Πορεύματος SE Gångtest



GB Detection area DE Erfassungsbereich
FR Zone de détection NL Detectiegebied
FI Tunnistusalue DK Registreringsområde
IT Area rilevazione ES Zona de detección
PT Área de deteção GR Περιοχή ανίχνευσης
SE Detektionsområde



GB Operating instructions DE Betriebsmodus FR Instructions opérationnelles
NL Bedieningsvoorschriften FI Käyttöohjeet DK Betjeningsvejledning IT Istruzioni operative
ES Instrucciones de funcionamiento PT Instruções de funcionamento GR Οδηγίες λειτουργίας
SE Bruksanvisning



GB Trouble shooting DE Fehlerbehebung FR Dépannage NL Probleemoplossing FI Vianmääritys DK Problemløsning
IT Risoluzione dei problemi ES Solución de problemas PT Resolução de problemas C2 Αντιμετώπιση προβλημάτων
SE Felsökning

livewell.honeywellhome.com