


Applicable to:

- EcoFlow STREAM Ultra (used as the example product in this guide)
- EcoFlow STREAM Pro
- EcoFlow STREAM AC Pro

1 Connect the STREAM devices in parallel.



2 Connect the main device to the grid.

- Perform the parallel connection only when the main device is disconnected from your home electrical circuit.
- You can parallel up to 6 devices in a STREAM system.
- Keep the protective cap on any unused terminal.