

5 in

Troubleshooting Tip: If charging does not begin, check that the earbuds are seated properly in the case and that the charging contacts are clean.