

Support:
Customercare@ubeesize.com



**UBeesize 67-inch
Selfie Stick Tripod
with Bluetooth Remote**

Open the tripod stand

Rotate the knob counterclockwise to release the center brace.

Gently pull the legs out to the open position and rotate the knob clockwise until secure.



Attach a camera or phone holder to the tripod head

Insert the plate's mounting screw to your socket of camera's tripod or phone holder and fasten the screw using the screw-head until fully tightened.



Fasten the screw on the tripod head as showed in the pic



For Cameras with 1/4 Thread Hole




For Cell Phone Holder Fit for between 2.25"-3.75" wide



For GoPro Camera Adapter included



4 SECTIONS





Phone Holder
(Extends from 2.3"-4.5")



Standard 1/4" Screw
(For cellphones and cameras)



Free Rotation Plate
(360°Pan & 180°Tilt)



Quick Flip Locks
(Height adjustable)



Non-slip Rubber Feet



Base Locking Knob



CAPTURE A BROADER VIEW

OURS:

EXTENSIBLE 67 INCH LONG



OTHERS:

