FW047 - Camconnect Pro(Al-Box1) Firmware Update Manual

There are two methods to upgrade the FW, please find the instruction from following chapters.

- ■FW Upgrade by OTA
- ■FW Upgrade by Webpage

* "Browser update MUST unplug/plug power supply" while "internet update, NO NEED to unplug/plug power supply".

FW Upgrade by OTA

1. Tools


Power adapter / Power Cord	HDMI cable Ethernet Cable	Monitor

2. FW Update - Video

1.1 Connect the Al-BOX1 with Power, Monitor and Ethernet.




1.2 Please find the following screen.




1.3 The Firmware update will pops up in seconds.




1.4 Please Click [Update Now] to preceed update.



1.5 FW Update will start automatically. (Around 6 minutes taken)




1.6 When FW Update finish, Camconnect Pro will restart and you can check version on upper right corner.



FW Upgrade by Webpage


1 Device and Tool Preparation

1.1 Please prepare following devices and tools before FW upgrade.




2 Connections

- 2.1 Connecting via switch or router.
- Make sure the IP address range are the same and if possible avoid multiple opened network interface card on PC you are sending FW from.




3 FW Update


- 3.1 Open browser and enter the IP address of AI-Box1 in the address bar.
 - You can check the IP address from the [Operation Interface].



- 3.2 Select [System]> [Setting]> [Maintenance]> [Firmware Update] to select firmware file and start updating.
 - Webpage Update function is available after FW version v1.5.6.



3.3 FW download starts(around 5-10 minutes taken), please check the status from HDMI output or webpage, don't unplug the cables and refresh the browser.











- 3.4 After FW update process is complete, the system will be shut down automatically, please power on or re-plug the power adapter when the HDMI output off and the fan is running at a high speed.
 - *Note: This message will show around 1-2 minutes, please <u>DO NOT</u> unplug the cables until hearing the fan at a high speed.







3.5 Please enter the IP address, login webpage again and check the FW version from [About]> [Version].

