

<div data-bbox="579 80 676 127" data-label="Text"><p>SW2</p></div> <div data-bbox="236 195 603 556" data-label="Image"></div> <div data-bbox="223 616 616 647" data-label="Caption"><p>Dimmer Smart Switch Instruction</p></div>	<div data-bbox="899 104 1139 136" data-label="Section-Header"><p>Product Overview</p></div> <div data-bbox="756 185 1126 647" data-label="Image"></div>	<div data-bbox="1376 104 1592 136" data-label="Section-Header"><p>Before you install</p></div> <div data-bbox="1376 152 1875 258" data-label="Text"><p>WARNING! RISK OF ELECTRIC SHOCK. Incorrect installation could be dangerous or illegal, multiple breakers may need to be de-energized for safe installation. Please call a professional electrician if you are unfamiliar or uncomfortable with electrical work.</p></div> <div data-bbox="1406 296 1852 443" data-label="Image"></div> <div data-bbox="1376 467 1875 632" data-label="Text"><p>Note: a non-metalized type listed face plateshall be employed for installation</p><p>Make sure your wiring is compatible. The smart dimmer switch replaces single pole switches only. If your light can be turned on from two different wall switches, that's a 3-way switch and dimmer smart switch is not compatible.</p></div>	<div data-bbox="1979 110 2479 175" data-label="Text"><p>Note:This device features easy-to-use technology making it simple for you to control your dimmable lighting.Smart bulb can't be dimmed by this switch.</p></div> <div data-bbox="1979 237 2282 269" data-label="Section-Header"><p>Install the Light Switch</p></div> <div data-bbox="2009 288 2469 641" data-label="Image"></div>
--	---	---	--

<div data-bbox="169 813 669 914" data-label="Text"><p>Step 1: Shut OFF the power at the circuit breaker for the switch you are replacing. You may need to shut OFF more than one circuit breaker/switch to make sure the switch you're working on is powered OFF.</p></div> <div data-bbox="169 938 669 1013" data-label="Text"><p>IMPORTANT: USE A NON-CONTACT VOLTAGE DETECTOR OR FLIP YOUR LIGHT SWITCH A FEW TIMES TO MAKE SURE THAT THE POWER IS OFF</p></div> <div data-bbox="169 1035 579 1058" data-label="Text"><p>Step 3: Identify the wires on your device as follows</p></div> <div data-bbox="169 1078 669 1179" data-label="Text"><p>Step 4 : Install the smart Light Switch. Connect two wires from the smart Light Switch to the available Switch (Live / Load) wires . In case you found more than one wire , just place them into the wire nut .</p></div> <div data-bbox="169 1199 669 1221" data-label="Text"><p>NOTE : The wire nut is the cap-like object connecting the wires</p></div>	<div data-bbox="776 813 1276 863" data-label="Text"><p>Step 5 : If you have a wire (optional)disconnect it from the old switch and connect it to the green wire on the Switch.</p></div> <div data-bbox="776 887 1276 988" data-label="Text"><p>Step 6 : Unscrew the wire nut that is holding together the existing Neutral wires. Connect the white wire from the smart Light Switch to the outlet's exposed Neutral wires. Securely screw them together inside the wire nut.</p></div> <div data-bbox="776 1014 929 1046" data-label="Section-Header"><p>Parameters</p></div> <div data-bbox="776 1058 1276 1347" data-label="Text"><p>Model: SW2 Input: 120V~ 50/60Hz 4A Output: 120V ~ 50/60Hz 4A Max. for General use; 1.245, FLA Motor Power Supply Mode: Neutral+Live Wire Wi-Fi 802.11 b/g/n, 2.4GHz(only) Operating Temp. 0~40 °C Operating Control Type 1 Pollution Degree: 2 Impulse Voltage: 2500V</p></div>	<div data-bbox="1376 813 1449 845" data-label="Section-Header"><p>Reset</p></div> <div data-bbox="1376 855 1875 907" data-label="Text"><p>Turn on the power, hold the Reset button for 5 seconds and let it go when the Switch starts to flash quickly, the reset is successful.</p></div> <div data-bbox="1376 922 1875 997" data-label="Text"><p>When the Switch is in a new network environment, you need to restore the factory settings, and then reconnect to the network.</p></div> <div data-bbox="1376 1022 1695 1053" data-label="Section-Header"><p>Warnings and Precautions</p></div> <div data-bbox="1376 1064 1875 1298" data-label="List-Group"><ul style="list-style-type: none">• Keep it out of the reach of children and pets.• Do not use this product in humid environments or outdoors. It's for indoor use only.• Do not place this product near heating devices, such as microwave ovens, stoves, or radiators.• Protect the product from extreme temperatures, direct sunlight, strong jolts, high humidity, moisture, flammable gases, vapors and solvents.</div>	<div data-bbox="1969 813 2475 1085" data-label="List-Group"><ul style="list-style-type: none">• Do not disassemble, modify, or repair your device, and ask help from the authorized professionals for device malfunction.• Do not use the device when it is no longer working properly or visibly damaged.• Do not store the device for extended periods in poor ambient conditions.• Never use aggressive detergents such as rubbing alcohol or other chemical solutions because these could damage the casing or even impair the functioning of the product.</div> <div data-bbox="1979 1103 2475 1177" data-label="Text"><p>Note: The image shown in the manual is indicative only. If there is inconsistency between the image and the actual product, the actual product shall govern.</p></div> <div data-bbox="1969 1236 2422 1309" data-label="Image"></div> <div data-bbox="1979 1359 2142 1381" data-label="Text"><p>4.02.000.0693 V1.0</p></div>
--	--	--	--

料号: 4.02.000.0693 V1.0
名称: SW2 说明书
材质: 105克哑粉纸,双面印, 风琴折
尺寸: 80X90 mm