

Quick Start Guide

TC ELECTRONIC PIPELINE TAP TREMOLO

USB - Connects to your computer for firmware updates and TonePrint editing.

Power Input - Connect a 9V / >100 mA power supply.

Speed - Controls the speed of the tremolo effect.

Depth - Controls the amount of level drop between peaks.

Volume - Varies the output level from unity gain to 6 dB of additional boost.

Subdivision - Sets the tremolo to various rhythmic subdivisions of the active tempo.

Output

Input

Footswitch - Turns the effect on and off. Press and hold for 1½ seconds to access Tap Tempo mode.

Mode - Choose between standard Vintage, TonePrint and Square settings.



Visit [tcelectronic.com](https://www.tcelectronic.com) to download the full manual