


















































































Original	Recharge	Original	Recharge
 Power	 Power	 Sleep	 Sleep
 Tv/AV	 AV	 Edit	 Smart
 1	 1	 Info	 Info
 2	 2	 Mute	 Mute
 3	 3	 Menu	 Menu
 4	 4	 Still	 Media
 5	 5	 EPG	 Guide
 6	 6	 Red	 Red
 7	 7	 Green	 Green
 8	 8	 Yellow	 Yellow
 9	 9	 Blue	 Blue
 0	 0	 Up	 Up
 -/-	 Shift + Guide	 Down	 Down
 Recall	 Pre Ch	 Right	 Right
 P.Mode	 Shift + Format	 Left	 Left
 S.Mode	 Shift + Dual	 Enter	 Ok
 Nicam	 Options	 CH+	 Ch +

Original	Recharge	Original	Recharge
 Sleep	 Sleep	 Smart	 Smart
 Edit	 Smart	 Info	 Info
 Info	 Info	 Mute	 Mute
 Mute	 Mute	 Menu	 Menu
 Menu	 Menu	 Media	 Media
 Still	 Media	 Guide	 Guide
 EPG	 Guide	 Red	 Red
 Red	 Red	 Green	 Green
 Green	 Green	 Yellow	 Yellow
 Yellow	 Yellow	 Blue	 Blue
 Blue	 Blue	 Up	 Up
 Up	 Up	 Down	 Down
 Down	 Down	 Right	 Right
 Right	 Right	 Left	 Left
 Left	 Left	 Ok	 Ok
 Enter	 Ok	 Ch +	 Ch +
 CH+	 Ch +		





Original		Rechange		Original	Rechange
	CH-		Ch -		
	Vol+		Vol +		
	Vol-		Vol -		
	3D N.R		3D		
	FAV	 + 	Shift + Pre Ch		
	Text		Text		
	Cancel		Exit		
	Index		List		
	Subpage		Eject		
	Hold		Back		
	Size		Format		
	FAV+	 + 	Shift + Ch +		
	FAV-	 + 	Shift + Ch -		
	Tv/Radio		TV/R		
	Audio		D. Menu		
	Lang		Dual		
	Subtitle		Subt		

