





















<div><div>SwitchBot Remote</div><div>User Manual</div><div></div><div>Please read this user manual carefully before using your device.</div></div>	<div><div>Package Contents</div><div><div> Remote × 1</div><div> User Manual × 1</div><div> 3M Adhesive Tape × 2</div><div> CR2450 Button Cell Battery × 1 (Installed in the Remote)</div><div> Remote Holder × 1</div></div></div>	<div><div>List of Components</div><div><div> Concave Key</div><div> Convex Key</div><div> Battery Box</div><div> Strap-hole</div></div></div>	<div><div>Getting Started</div><div>1. Download the SwitchBot app via the Apple App Store or Google Play Store.</div><div>2. Open our app and register a SwitchBot account or sign in directly if you already have one.</div><div><div> App Store</div><div> Google Play</div><div> iOS 11.0+</div><div> Android OS 5.0+</div></div></div>	<div>3. Open the battery cover, remove the plastic battery isolation tab, and you will see the indicator light start flashing.</div> <div></div>	<div>4. Close the battery cover and turn on Bluetooth on your phone. Open the SwitchBot app, tap "+" on the top right of the home page, find the Remote icon and select. Then follow the instructions and add your device.</div> <div></div>	<div><div>Placement</div><div>After adding your Remote, you may place it anywhere.</div><div>Option 1: Place it on a table.</div><div></div></div>	<div>Option 2: Put it into the Remote holder. Peel off the tape liner on the back of the holder, stick it to a smooth surface and press it for 30 seconds to ensure it is firmly attached. Then put your Remote into the holder.</div> <div></div>	<div>Option 3: Add a lanyard to your Remote through the strap-hole for portable use. You may need to purchase a lanyard separately.</div> <div></div>	<div><div>Pairing Remote</div><div>You can pair your Remote with SwitchBot devices like a Bot or a Curtain to control them.</div><div>How to pair a Remote:</div><div>1. When pairing, place your phone, Remote and the target device close to each other.</div><div>2. Open the SwitchBot app, tap the Remote card on the home page, tap the Key icon below Key Settings, then your phone will start to scan nearby available devices. Select your target device and set Remote actions for it.</div></div>	<div><div>Mapping Keys</div><div>The two keys on your Remote can be set individually to trigger actions of two different devices. One key can only trigger one action.</div><div>For example, you can set the action of the concave key as closeing/opening your Curtain, and the concave key as turning on/off your Bot.</div></div>	<div><div>www.switch-bot.com</div><div>V2.0-2206</div></div>
---	--	---	--	---	--	--	--	---	--	---	--

<div><div>Low Battery</div><div>When you see a red battery icon appear on the Remote card on the app home page, you may need to replace the battery.</div></div>	<div><div>Resetting Factory Settings</div><div>Press and hold both keys, and you will see the indicator light starts flashing. Hold the keys for 15 seconds and release when the light stops flashing. Then your Remote will emit a beep sound and the indicator light will light up for 1.5 seconds. Now your remote has been reset to factory settings.</div><div></div></div>	<div><div>Note: Since all previous settings of your remote will be deleted after resetting, you will need to pair your Remote again.</div><div><div>Specifications</div><div>Model: W0301700</div><div>Color: White</div><div>Material: ABS plastic with UV-resistant coating</div><div>Size: 37.1 × 43.1 × 13.4 mm (1.5 × 1.7 × 0.5 in.)</div><div>Weight (with battery): 17.7 g (0.6 oz.)</div><div>Battery: CR2450</div><div>Network Connectivity: Bluetooth Low Energy</div></div></div>	<div><div>Return & Refund Policy</div><div>This product has a one-year warranty which begins from the date of purchase. Should the following situations occur, your warranty and/or your eligibility for a return or refund may not be valid.</div><div><ul style="list-style-type: none">Intended damage or abuse.Inappropriate storage (including dropping or soaking in water).Unauthorized modifying or repair of product.Natural wear of product.Natural disasters.</div></div>	<div><div>Contact & Support</div><div>Setup and Troubleshooting: support.switch-bot.com</div><div>Support Email: support@wondertechlabs.com</div><div>Feedback: If you have any concerns or problems when using our products, please send feedback via our app through the Profile > Feedback page.</div></div>	<div><div>CE/UKCA Warning</div><div>RF exposure information: The EIRP power of the device at maximal case is below the exempt condition, 20 mW specified in EN 62479: 2010. RF exposure assessment has been performed to prove that this unit will not generate the harmful EM emission above the reference level as specified in EC Council Recommendation(1999/519/EC).</div><div><div>CE Doc</div><div>Hereby, Woan Technology (Shenzhen) Co., Ltd. declares that the radio equipment type W0301700 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: support.switch-bot.com</div></div><div><div>UKCA Doc</div><div>Hereby, Woan Technology (Shenzhen) Co., Ltd. declares that the radio equipment type W0301700 is in compliance with UK Radio Equipment Regulations (SI 2017/1206). The full text of the UK declaration of conformity is available at the following internet address: support.switch-bot.com</div></div><div>This product can be used in EU member states and UK</div><div>Manufacturer: Woan Technology (Shenzhen) Co., Ltd.</div><div>Address: Room 1101, Qiancheng Commercial Center, No. 5 Haicheng Road, Mabu Community, Xixiang Subdistrict, Bao'an District, Shenzhen, Guangdong, P.R.China, 518100</div></div>	<div>EU Importer Name: Amazon Services Europe</div> <div>Importer Address: 38 Avenue John F Kennedy, L-1855 Luxembourg</div> <div>Wi-Fi: 2412 MHz to 2472 MHz</div> <div>Operation temperature: −20 °C to 60 °C</div> <div><div>FCC Warning</div><div>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:</div><div>(1) This device may not cause harmful interference.</div><div>(2) This device must accept any interference received, including interference that may cause undesired operation.</div></div>
--	---	--	--	--	--	---