


AutoWand™ User Manual

- 1. Enter Setting Mode** (motor will automatically leave setting mode if there is no action for 10s)




Press SET for 1s
Motor will jog once when entering setting mode

- 2. Switch Direction** (use only if the direction of movement is reversed)




In setting mode, press DOWN
Motor will jog once after direction is switched

- 3. Set Upper and/or Lower Limit**




Press SET on the bottom of the handle
Motor will jog once after entering limit setting mode
Press UP to set Up limit
Or Press DOWN to set Down limit
Adjust shade to desired position, Press SET on bottom of handle again
Motor will jog once when limit is saved

- 4. Set Favorite Position** (Optional setting: The shade will stop at this additional saved position each time the shade is raised or lowered)



Adjust shade to desired Favorite position
Press SET on bottom of handle
Motor will jog once after entering Limit set mode
Press SET on the bottom of handle again
Motor will jog once when Favorite position is saved

- 5. Erase all Limits**



Press SET on bottom of handle for 7s
Motor will jog once after button is pressed
Motor will jog again to indicate that limits are erased