

Important!
Do not touch screen.

Do not apply pressure. Support from bezel.

What's in the box
Smart TV, power cable, remote, and TV feet with screws.

Accessory type and quantity may vary depending on the model.

What you need
Phillips head screwdriver, broadband internet connection, and VIZIO Mobile app.

(Tools not included)

Wall mounting your TV?
See the full user manual for wall mount specifications.

Wall mount kit not included

1 TV stand setup

Support the TV on both sides and lay on a padded flat surface. Install the TV feet according to the image below.

TV feet may vary depending on model.

2 TV remote

Insert two AAA batteries into the remote control.

(Batteries not included)

NOTE: The remote control vary depend of model: The buttons on the remote control may have a different name or location than the remote control shows in this manual.

3 Connect

Connect the TV power cable into a wall outlet.

If you have a soundbar, connect it to your TV's HDMI eARC port.

NOTES:
The cables mentioned in this manual is not supplied with your unit.
The actual number of ports and their locations may vary depending on the model.

4 On-screen setup

Follow the on-screen instructions to complete your TV setup and enjoy.

See the online user manual for a full walk-through.

NOTE: The actual descriptions of control panel and their locations may vary depending on the model.

Take control with VIZIO Mobile

The smarter, easier way to control and personalize your TV.

Scan to download
*VIZIO Account required for Smart TV functionality and product updates.

Device control
Launch your favorite apps, movies, and TV shows, as well as powering on/off devices, adjusting volume and more.

Content on command
Use voice to access your favorite apps, movies, and TV shows.

VIZIOgram
Instantly share life's memorable moments to your VIZIO TV.

VIZIO Account
A single place to view subscriptions, track receipts, and update payment methods.

Get to know your Smart TV

Picture mode
Adjust to your perfect picture. Press the settings button (⚙️) on your VIZIO TV remote and select PICTURE MODE. We recommend BRIGHT.

Customize your apps
Get to your shows faster. Head to your VIZIO Home Screen and find APPS on the sidebar. From APPS navigate to HOME SCREEN APPS to customize.

ClearDialog
Hear every word with the ClearDialog setting. Press the settings button (⚙️) on your VIZIO TV remote and select ALL SETTINGS > AUDIO > ClearDialog, and choose a level.

Bluetooth headphone support
Pair your Bluetooth headphones. Press the settings button (⚙️) on your VIZIO TV remote and select PAIR HEADPHONES.

Soundbar audio control menu
Audio settings may be adjusted easily via the on-screen menu, when connected to select VIZIO Soundbars using HDMI.

Give a voice to your commands
VIZIO Voice Remote lets you control your favorite content with your voice with the click of a button.

VIZIO WATCHFREE+

Enjoy exclusive access to 260+ free channels and 6,000+ movies and shows On Demand.

The images shown in this guide are for illustrative purposes only and may be subject to change.

