
RFC-XL

Quick Reference Guide

English EN
Espal ES
Franis FR
Deutsch DE
Italiano IT
Nederlands NL



Scan the QR code to access the product page, warranty terms, and the complete User Manual







QUICK REFERENCE GUIDE

EN



Safety Notes

These Safety Notes include important information about installation, use, and maintenance of RFC-XL.



ALWAYS:

In the event of a serious operating problem, stop using immediately.

DO NOT:

Open this product or attempt any repairs. It contains no user-serviceable parts.

Operate in temperatures higher than 104 (40?C).

Expose to environments that exceed the Ingress Protection (IP) rating.

Expose to rain or moisture.

Use outdoors.

Submerge.

Leave outdoors for extended periods of time.

Expose to corrosive environmental conditions such as temperature, humidity, salinity, pressure, radiation, or shock.

Set this product on a flammable surface.

FCC Compliance

This device complies with Part 15 Part B of the FCC rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.

What is Included

RFC-XL

Alkaline battery (A23)

Quick Reference Guide

Battery Charge Notes

The is battery operated. Ensure that the Alkaline battery (A23) is installed prior to operating the remote.



ALWAYS:


Follow local regulations when disposing of batteries.

Turn off the unit when not in use.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- --Reorient or relocate the receiving antenna.
- --Increase the separation between the device and receiver.
- --Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- --Consult the dealer or an experienced radio/TV technician for help







indicator light	From left to right: signal lamp, group 1, group 2,	
	group 3, group 4	
(h)	Remote control backlight switch	
	Remote control backlight switch	
color palette	RGB Hybrid dimming	
GROUP	Remote control group setting (press the GRUOP key	
	to enter the group setting mode, and then press	
	RED, GREEN, BLUE, AMBER (corresponding to	
	groups 1 to 4) to set the group. After setting, press	
	any other key to exit the group setting.)	
BLACK OUT	Closed light (pair key)	
AUTO	Self-walking mode P 1-P23 (can select program by	
	\wedge or \vee)	
SOUND	Voice-activated mode	
STROBE	Stroboscopic mode (can select stroboscopic speed	
	by \land , \lor key)	
DIMMER	Brightness adjustment (can be adjusted by \wedge or	
	∨)	
SPEED/SENSITIVITY	Effective in bootwalk and voice-control modes (can	
	control bootwalk speed or voice-control sensitivity	
	by \land , \lor key)	
FADE	Self-walking effective fade and fade effect	



RED、GREEN、BLUE、 AMBER、WHITE、UV	Corresponding Par lamp light color R, G, B, A, W, UV	
PAN	Horizontal scroll	
TILT	vertical movement	
COLOR	COLOR Static color mode (Can switch static color by \land , \lor key)	
GOBO	Rotation Gobo Select	
PRISM	Prism adjustment	
FOCUS	FOCUS Adjust the focus	
zoom	Zoom Scale	
GOBO ROTATE	GOBO ROTATE the pattern	
PRISM ROTATE	PRISM ROTATE. Prism rotate	
FREEZE	FREEZE the program	



Contact Us

General Information	Technical Support
Chauvet World Headquarters	
Address: 3360 Davie Rd.	Voice: (844) 393-7575
Davie, FL 33314	Fax: (954) 756-8015
Voice: (954) 577-4455	Email: chauvetcs@chauvetlighting.com
Fax: (954) 929-5560	
Toll Free: (800) 762-1084	Website: www.chauvetdj.com
Chauvet U.K.	
Address: Unit 1C	Email: <u>UKtech@chauvetlighting.eu</u>
Brookhill Road Industrial Estate	
Pinxton, Nottingham, UK	Website: www.chauvetdj.eu
NG16 6NT	
Voice: +44 (0) 1773 511115	
Fax: +44 (0) 1773 511110	
Chauvet Benelux	
Address: Stokstraat 18	Email: BNLtech@chauvetlighting.eu
9770 Kruishoutem	
Belgium	Website: www.chauvetdj.eu
Voice: +32 9 388 93 97	
Chauvet France	
Address: 3, Rue Amp?re 91380 Chilly-Mazarin	Email: FRtech@chauvetlighting.fr
France	Website: www.chauvetdj.eu
Voice: +33 1 78 85 33 59	
Chauvet Germany	
Address: Bruno-Bgel-Str. 11 28759 Bremen	Email: <u>DEtech@chauvetlighting.de</u>
Germany	Website: www.chauvetdj.eu
Voice: +49 421 62 60 20	
Chauvet Mexico	
Address: Av. de las Partidas 34 - 3B (Entrance by Calle 2)	Email: servicio@chauvet.com.mx
Zona Industrial Lerma	Website: www.chauvetdj.mx
Lerma, Edo. de Mico, CP 52000	
Voice: +52 (728) 690-2010	

Visit the applicable website above to verify our contact information and instructions to request support. Outside the U.S., U.K., Ireland, Mexico, France, Germany, or Benelux, contact the dealer of record.

RFC-XL QRG ML6 Rev. 1 ©Copyright 2022 Chauvet All rights reserved



RoHS