

UNDER CABINET LIGHTS



USER GUIDE

tzumi®

INTRODUCTION

With the tzumi® Under Cabinet Lights, you can have hands-free customized lighting at your fingertips for late night snack runs. Our built-in motion sensor settings keep the lights on only when there's movement. With an installation that's renter friendly for apartments, set up is going to be a breeze. Let's get you set up.

FEATURES


- Motion Sensor Settings
- Hands Free Lighting
- 3 Light Modes + Brightness Adjustment

WHAT'S IN THE BOX:

- 3 Under Cabinet Lights
- 6 Magnet Stickers
- 6 Mounting Magnets
- 3 USB-C Charging Cables
- 1 User Guide

PRODUCT DIAGRAM

- A. Power/Mode Button
B. Color Tone Button
C. USB-C Charging Port
D. Motion Sensor
E. Magnet Stickers
F. Mounting Magnets



CUSTOMER SUPPORT

If you have any questions about using this product, we are here to help! Call or email us, and an experienced customer support representative will be happy to assist you: **1-855-GO-TZUMI** or **support@tzumi.com**.

tzumi®
live awesome.

tzumi® Under Cabinet Lights. Item No. 30206. Distributed by tzumi® Inc. NY, NY, 10016. ©Copyright 2024. All Rights Reserved. Made in China. All other trademarks and trade names are the property of their respective owners. All pictures shown are for illustration purposes only. Actual product may vary due to product enhancement. Subject to change without prior notice.



INSTALLING THE CABINET LIGHTS

1. To install the under cabinet lights, clean the intended flat surface area you plan to install the lights, to ensure the area is free of debris or dirt.
2. Remove the adhesive of the metal plates and attach them to the back of your under cabinet lights.
3. Remove two of the adhesive magnet stickers and attach the magnets onto the intended surface area.
4. Place the under cabinet light flush with the magnets and remove your hands, the light should remain connected to the magnets. Your light is ready to use.

CHARGING THE CABINET LIGHTS

1. To charge the lights, plug one end of the included USB-C charging cable into the light's USB-C port and the other end into a USB power source.
2. The indicator light in the motion sensor will glow solid red while charging and turn off when fully charged.

USING THE CABINET LIGHTS

1. Press the Power Button once for Steady Light mode.
2. Press the Power Button twice for Night mode.
 - In Night mode, the cabinet lights will only activate when the room is dark and movement is detected.
3. Press the Power Button three times for Day+Night mode.
 - In Day+Night mode, the cabinet lights will activate any time of day movement is detected.
4. Press the Power Button a fourth time to turn the cabinet light OFF.
Note: The under cabinet light will flash each time you switch modes.
5. Whenever motion is detected in Night or Day + Night mode, the light will turn on. After 15 seconds of inactivity, the light will turn off.
6. Press the Color Tone Button to switch between Warm, Natural, or White lighting.
7. Press and hold the Color Tone Button to adjust the brightness of the light in any mode.
8. Once you've customized your settings, place the under cabinet light back on the wall or cabinet mount you've created. The settings will remain the same as the last inputted until you customize them again.

CARE AND MAINTENANCE

- To clean the under cabinet light, wipe with a damp cloth.
- It's recommended to periodically charge the light when being stored for long periods of time.

PRODUCT SPECIFICATION

- Input: 5V/0.3A
- Power: 1W
- Product size: 7.87" x 1.57" 0.43"
- Weight: 0.17 lbs x 3
- Charging Time: Up to 4 hours
- Battery: 1000mAh
- Sensor Distance: 9–16 ft

WARNINGS & SAFETY INFORMATION

Before using this product, please read the following safety precautions carefully and keep this user guide for future reference.

- Do not drop this product.
- Do not stare directly into the LED light.
- Do not use this product for anything other than its intended purpose.
- This product is meant for indoor use only.
- Do not strike or apply excessive force to this unit, or place heavy objects on top of it.
- If you do not use this unit for a long time, store it in a dry location, away from extreme temperatures, humidity, and dust.
- Keep this device away from heat sources and extreme temperatures.
- Do not operate this unit with wet hands.
- Do not attempt to disassemble or modify this product. There are no user-serviceable parts inside this unit.
- Keep this unit out of the reach of children. This product is not a toy.
- Do not attempt to repair this product. Should this unit malfunction, take it to a qualified technician instead.