
# **MONSTER**




Monster Airmars XKT08

真无线蓝牙耳机



## 给充电盒充电

用Type-C 充电线连接充电盒到5V电源活配器



额定输入: 5V ===30mA( 耳机 ) 额定输入: 5V ===300mA( 充电盒 )

温馨提示: 关闭充电盒, 出现充电盒冰蓝灯闪烁时, 请及时给充电盒充电。

## 指示灯指南

模式	描述	声音提示		
开机	耳机冰蓝指示灯亮1秒	"Power on"		
关机	耳机红色指示灯闪三下熄灭	"Power off "		
配对	耳机红蓝指示灯交替闪烁	"Pairing"		
连接	耳机指示灯熄灭	"Connected"		
断开	耳机红蓝指示灯交替闪烁	"Disconnected"		
耳机低电	_	"Low Battery"		
充电盒给 耳机充电	耳机指示红灯常亮,充满熄灭	_		
充电盒低电	冰蓝指示灯闪烁	_		
给充电盒充电	红色指示灯闪烁	_		
充电盒充满	红色指示灯长亮			


方法一: 从充电仓取出耳机, 耳机自动开机。 方法二:长按功能键3秒,耳机开机。

方法一: 将耳机放回充电盒, 耳机关机。

方法二:与蓝牙设备断开连接3分钟后,自动关机。

方法一: 从仓取出耳机, 耳机自动开机并配对。

方法二: 打开智能设备的蓝牙列表, 搜索 "Monster Airmars XKT08" 进行配对,连接成功后,你会听到提示音 "Connected"。 \*超出距离,在断开连接3分钟内,回到有效距离,自动连接设备。




\* 如果产品长时间不使用,应先充满电,并确保设备处于关机状态。

\* 充电完成后,请将充电线拔出,避免长时间充电造成设备损坏。

## 触控键的操作

常规模式




------ 音量加: 単击右MFB □ 音量减: 单击左MFB

# 音乐播放模式

── 暂停/播放: 双击左/右MFB └── 下─曲: 三击右MFB

## 电话免提





任意一个耳机开机后未与蓝牙设备配对状态下,连续单击耳机功能键5次清 除配对信息后关机。

— 长按2秒右MFB进入音乐模式

- 1. 从充电盒取出耳机,不需按任何按键,耳机自动开机,连接或配对;耳机放入充电仓,充电 盒将自动给耳机充电, 耳机关机。
- 2. 常清洁,寿命长,如长期不用,建议15天充电1次,延长电池寿命,耳机尾塞 充电部分经 常用棉签酒精擦拭,能够帮助充电顺畅,避免接触不良,影响使用体验。
- 4. 由于本款产品采用无线连接方式,在日常使用过程中,受到环境、手机品牌、使用行为等因 素影响,可能在播放音乐过程中,会出现短暂、轻微的声音卡顿属于正常现象。
- 1. 长时间以高音量使用耳机可能会损害您的听力。建议只使用适当音量收听、通话和听
- 2. 请不要冲洗或将产品浸入水中,以免造成损坏
- 3. 不要自行拆卸产品及配件,以免导致损坏及保修失效。
- 4. 请勿使产品受到强烈冲击或震动以免损坏。
- 5. 请勿使用化学溶剂或清洗剂清洗产品。

Name of the Parts	Hazardous Substances 有害物质					
部件名称	Pb 铅	Hg 汞	Cd 镉	Cr(VI) 六价铬	PBB 多溴联苯	PBDE 多溴二苯醚
Housing 外壳	0	0	0	0	0	0
Loudspeakers 喇叭单元	0	0	0	0	0	0
PCBA 电路板组件	Х	0	0	0	0	0
Accessories 电源线 连接线	Х	0	0	0	0	0

This table is compiled according to SJ/T 11364. 本表格依据SJ/T 11364的规定编制。

- O: Indicates that this hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572. O:表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 标准规定的限量要求以下。
- X: Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.
- X:表示该有害物质至少在该部件的某一均质材料中含量超出 GB/T 26572 标准规定的限量要求。

根据FCC规则第15部分,本设备经过测试。符合B举数字设备的限制。这些限制旨在提供合理 的住宅设施中的有害干扰防护。该设备产生使用并可辐射射频能量,如果未按照规定安装和使 用该指示可能会对无线电通信造成有害干扰。然而,有不能保证在特定安装中不会发生干扰。 如果这个设备有对无线电或电视接收造成有害干扰,可通过转动来确定设备关闭和打开时,鼓 励用户尝试通过一个或多个以下更多措施:

- 重新定向或重新定位接收天线。
- 增加设备和接收器之间的间距。
- 设备连接到与接收器不同的电路上的插座已连接。
- -- 请咨询经销商或经验丰富的无线电/电视技术人员以获得帮助。

此设备符合FCC规则的第15部分。操作受以下两个条件限制条件

## (1)本装置不得引起有害干扰。

(2)本装置必须接受任何接收到的干扰,包括可能导致意外操作的干扰。未经合规责任方明确批 准的变更或修改可能使用用户对设备的操作权限失效。

### FCC ID:2A8PV-QSMXKT08



The period of use of this symbol (10 years) is the period during which harmful substances in electronic and electrical products will not leak or mutate under normal use conditions, and users of electronic products willnot cause serious pollution to the environment or serious damage to their personal and property when usingthis electronic product. 这标志的使用期间(10年)是电子电气产品中有害物质在正常使用的条件下不会发生外泄或突变。


电子产品用户使用该电子产品不会对环境造成严重污染或对其人身财产造成严重损害的期限。

# 尊敬的用户,本保修卡是您将来申请保修的凭证,请您配合销售商填写并妥善保管备用。 用户姓名 电子邮件 联系电话 邮政编码 诵讯地址 产品型号 产品条码 / 编号 / 批号

# 地 址 联系电话 销售日期 发票号码 备注




# MONSTER





Monster Airmars XKT08

BLUETOOTH WIRELESS HEADPHONES INSTRUCTIONS MANUAL



# charging case\*1





# Charge the charging case


Connect the charging case to the 5V power adapter with Type-C charging cable.



Tips: When the ice blue indicator flashes while closing the cover, please charge in time.

## Indicator guide

Mode	Description	Voice prompt		
Power On	Headphone ice blue indicator flash for 1 second	"Power on"		
Power off	Headphone red indicator flash 3 times	"Power off "		
Palring	The earphone flashes red and blue alternately	"Pairing"		
Connected	Headphone indicator off	"Connected"		
Disconnected	The earphone flashes red and blue alternately	"Disconnected"		
Low Battery	_	"Low Battery"		
Headphones placed in charging case	The headphone indicator light is always on, when fully charged it goes out	_		
Charging case low power	Ice blue indicator flashes	_		
Charging case charged	Red Indicator flashes	_		
Charging case fully charged	Red Indicator lights up			



Rated input:5V == 30mA(Headphone) Rated input:5V == 300mA(charging case)

Mode	Description	Voice prompt	
Power On	Headphone ice blue indicator flash for 1 second	"Power on"	'
Power off	Headphone red indicator flash 3 times	"Power off"	
Palring	The earphone flashes red and blue alternately	"Pairing"	
Connected	Headphone indicator off	"Connected"	
Disconnected	The earphone flashes red and blue alternately	"Disconnected"	
Low Battery	_	"Low Battery"	
Headphones placed in charging case	The headphone indicator light is always on, when fully charged it goes out	_	
Charging case low power	Ice blue indicator flashes		,
Charging case charged	Red Indicator flashes	_	
Charging case fully charged	Red Indicator lights up		'

Method 1: Take out the headphones from charging box, the headphones will turn on Method 2: Long press MFB for 3 seconds

Method 1: put the headphone/s into the charging case and close the cover. Method 2: after disconnected from the Bluetooth device for 3 minutes.

### Pairing


Method 1: take out the headphones from the charging case, the headphones wil start pairing automatically

MY DEVICES

Monster Airmars XKT08

Method 2: search and click for "Monster Airmars XKT08" on the Bluetooth list of the smart device, and when connection is successful, "Connected" will be heard.

\* Headphones will try reconnecting to the device with in 3 minutes when connection is lost.






 $^{\star}$  Fully charge the headphones and power off before an intended not-in -use


\* Unplug the charging cable after charging.

# Operation



# (Music playback





# Game/music switching: device connected



Either headphones is not connected to the bluetooth device when turned on, click the MFB 5 times to clear the previous pairing information and turn off.

- 1. Headphones will turn on automatically (needless to press any button) pair and connect the device when the charging case is opened. After placing the headphones in the charging case, they will turn off and automatic charging will start when the cover is closed.
- 2. Charging every 15 days will extend battery life when not in use often. Cleaning off dirt on the charging contacts by cotton swabs with alcohol will maintain a good contact for
- 3. Keep battery (battery pack) away from inflammables or excessive heat such as direct sunlight.
- 4. Intermittent is normal during playback for wireless products due to environmental factors. device brand, users' behavior, etc.

- 1. Do not use headphones at high volume for an extended period of time.
- 2. Keep the headphones away from dust and water.
- 3. Do not disassemble the headphones and accessories, otherwise warranty will be voided. 4. Keep headphones away from any impact or vibration.
- 5. Do not use any chemical solvents or cleaning agent on the headphones.

Name of the Parts		Hazardous Substances				
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Housing	0	0	0	0	0	0
Loudspeakers	0	0	0	0	0	0
PCBA	Х	0	0	0	0	0
Accessories	Х	0	0	0	0	0

### This table is compiled according to SJ/T 11364.

- requirement in GB/T 26572
- above the limit requirement in GB/T 26572

following measures:

- This equipment has been tested and found to comply with the limits for a Class Bdigital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the
- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiveris connectec.
- -- Consult the dealer or an experienced radio/TV technician for help.
- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference.
- (2) this device must accept any interference received, including interference thatmay Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## FCC ID:2A8PV-QSMXKT08

cause undesired operation.

Environment Friendly Use Period (EFUP)

The period of use of this symbol (10 years) is the period during which harmful substances in electronic and electrical products will not leak or mutate under normal use conditions, and users of electronic products willnot cause serious pollution to the environment or serious damage to their personal and property when usingthis electronic product.

# Warranty Service

Dear user, this warranty card is the proof of your future warranty application with the seller to fill it out and keep it for future use!

····								
User information								
User name		Email						
Contact number		ode						
Mailing address								
Product information								
Product name		Product	number					
Product barcode/Seri	ial number/Batch number							

Vendor information						
Name						
Address						
Contact number		Postal code				
Sales date		Invoice number				
Remark						

M MONSTER"	)			
rtificate of Approval				
oduct No:				
oduction Time: ( )				