

ENGLISH

Thank you for selecting the BearTrap® or BearTrap® 360 work light. As with any professional tool, reasonable care and maintenance of this product will provide years of dependable service. Please read this manual before using the BearTrap®.

SAVE THESE INSTRUCTIONS. This guide contains important safety and operating instructions for your BearTrap®.

LED SAFETY
⚠ CAUTION LED RADIATION (RG-2). DO NOT STARE INTO BEAM. MAY BE HARMFUL TO EYES. PER IEC 62471 Ed 1.0:2006-07.

MAGNET SAFETY
⚠ CAUTION THIS PRODUCT HAS A STRONG MAGNETIC FIELD. STRONG MAGNETS CAN BE HARMFUL TO PEOPLE WITH MEDICAL IMPLANTS AND ALSO PRESENT A PINCH HAZARD. KEEP A DISTANCE OF AT LEAST 12 INCHES FROM PACEMAKERS.

⚠ WARNING RISK OF INJURY. THE USE OF SUBSTANDARD OR AFTERMARKET COMPONENTS, MODIFICATIONS TO THE ORIGINAL PARTS, OR USE OF THIS WORK LIGHT WITH ANY INCOMPATIBLE PRODUCT MAY VOID WARRANTY AND COULD LEAD TO PRODUCT FAILURE OR PERSONAL INJURY.

PRODUCT SAFETY
⚠ CAUTION CLAMP PINCH HAZARD. USE CAUTION WHEN CLAMPING AND POSITIONING THE BEARTRAP®.

BATTERY SAFETY
⚠ CAUTION EXPLOSION RISK, BURN, AND FIRE HAZARD. DO NOT DISASSEMBLE, CRUSH, SHORT CIRCUIT, HEAT ABOVE 140°F (60°C), OR DISCARD IN FIRE. KEEP AWAY FROM CHILDREN. BATTERY MUST BE RECYCLED OR DISPOSED OF PROPERLY.

NOTICE The rechargeable battery contained in this product is recyclable. At the end of its useful life, under various country and state laws, it may be illegal to dispose of this battery in the municipal solid waste stream. Check with your local solid waste officials for details in your area for recycling options or proper disposal (In USA: RBRC).

CHARGING
NOTICE Fully charge battery before first use.

To charge the BearTrap®, first turn off the work light. Plug the AC charger into a power source, then fold back the rubber cover on the back of the work light, plug the 90-degree barrel connector of the charger into the exposed port. The power button will illuminate red for charging and green for charged. The charge cord may be connected continuously when not in use. There is no danger of overcharging.

Using the Streamlight charge cord, the BearTrap® recharges in 5.5 hours.

The work light is designed to run continuously if AC power is available. Insert the cord under the cord retainers to secure the wire.

NOTE: The batteries will charge while in constant use, but at a reduced rate.


GENERAL OPERATION
The power button is located on the front face of the light near the top. Depress the power button to turn the light on low spot mode. Each subsequent press will enable medium and high modes. A fourth press of the button will turn the work light off. If there is a pause of two seconds or more between button pushes, the next press of the button will turn the light off.

To access the flood mode, turn on the work light, then press and hold the button for two seconds. The work light will now function in the same manner as spot with low, medium, and high modes. To return to spot mode, repeat the press and hold sequence.

While the work light is on, the power button indicates charge state. The indicator progresses from green to yellow to red and then flashing red when the battery needs to be charged.

The work light will stand on a flat surface and will clamp to virtually any planar surface (door/table) or round surface (pole/pipe). The wire handle is useful to open the clamp. The base includes three magnets to hold the work light on magnetic surfaces.

PDF NOTICE The magnets are very strong. Avoid surfaces that are vulnerable to scratching such as painted metal.



As illustrated above, the BearTrap® body can rotate and be oriented in a variety of ways. Additionally, the body can be rotated through the clamp mechanism for other mounting options. Simply pull the clamp open and rotate the body through the opening. The wire handle may need to be moved to allow full range of motion of the body.

PRODUCT USE
Streamlight work lights are intended for use as high intensity, heavy duty, and portable light sources. Use of Streamlight work lights for any purpose other than as light sources is specifically discouraged by the manufacturer. Streamlight specifically disclaims liability for other than recommended use.

NOTICE Be sure to use only genuine Streamlight replacement parts to ensure product safety. Substitution may invalidate the product approval. Do not try to repair the unit yourself. Send to a qualified service facility or return it to the factory.

Streamlight Limited Lifetime Warranty
Streamlight warrants this product to be free of defects for a lifetime of use except for batteries and bulbs, abuse and normal wear. We will repair, replace or refund the purchase price of this product should we determine it to be defective. This limited lifetime warranty also excludes rechargeable batteries, chargers, switches and electronics which have a 2 year warranty with proof of purchase. **THIS IS THE ONLY WARRANTY, EXPRESSED OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES ARE EXPRESSLY DISCLAIMED EXCEPT WHERE SUCH LIMITATION IS PROHIBITED BY LAW.** You may have other specific legal rights which vary by jurisdiction.

Go to www.streamlight.com/support for a complete copy of the warranty. To register your product, go to www.streamlight.com (Online Product Registration). Retain your receipt or any proof of purchase

SERVICE OPTIONS
The BearTrap® series work lights contain few user-serviceable parts.

For service options, go to www.streamlight.com/support/service and complete the Online Service Request for factory service or to find the location of an authorized Streamlight repair center near you.

Or contact:
Customer Service
STREAMLIGHT, INC.
30 Eagleville Road
Suite 100
Eagleville, PA U.S.A. 19403-3996
Phone: (800) 523-7488 Toll-Free / +1 (610) 631-0600
Fax: (800) 220-7007 / +1 (610) 631-0712



STREAMLIGHT®

BEARTRAP® SERIES

Operating Instructions
Instrucciones de funcionamiento
Instructions d'utilisation
Bedienungsanleitung

available at **BrightGuy.com**

IMPORTANT:
FULLY CHARGE BATTERY
BEFORE FIRST USE.

IMPORTANT :
CHARGER COMPLÈTEMENT LA PILE
AVANT LA PREMIÈRE UTILISATION.

IMPORTANTE:
CARGUE LA PILA COMPLETAMENTE
ANTES DE USARLA POR PRIMERA VEZ.

WICHTIG:
LADEN SIE DIE BATTERIE VOR DEM
ERSTEN GEBRAUCH VOLL AUF.

EU Authorized Representative:
Falcon Logistics B.V., Hoeksteen 26 F,
2132 MS Hoofddorp, Netherlands
For compliance information, please visit
www.streamlight.com/compliance

