


NORDLI



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.




NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.



NEVER open more than one drawer at a time.


Place heaviest items in the lowest drawers.

English


Read and follow each step of the instruction carefully.









1




2




3




4




5




6








7






8







10




11




12




13




14




15









16






17





18



19

