

Scan the QR code to install the "Clabel trade"APP.




1.How to load the label paper correctly?

(If load it incorrectly, the label paper may not function properly.)




2.How to get "Clabel trade" APP?




3. How to Connect to "Clabel trade" APP?



1. Turn on Phone Bluetooth.



2. Open the "Clabel trade" App, and click the button in the upper right corner.



3. Find the 220B device and connected.

4. Where to turn on the machine? And how to tear off the printing paper?

Long press the power supply button for 2 seconds, then you can start to print



Face the serrations and tear the label paper down.


5. What is the width of the label paper? And what is the function of the Baffle of the paper bin?



The diagram shows a black Clabel printer with its top cover open. A blue arrow points from the printer's paper bin to a detailed inset of the bin. The inset shows a scale for 'Label Width: 20-55mm' with an 'Adjustable' slider. The printer has a power button and a Clabel logo on the front.

1. Put label paper width 20-55mm (0.78-2.95inch) in the paper bin. The effective print width is 48mm (1.88inch). The baffle has a lock button, which can be used to unlock/lock the bezel.
2. This can fix the label paper in the paper bin and make the printing process more stable.

6. How to Contact Customer Service in Case of Problems?



The illustration shows a woman with brown hair wearing a headset and a black blazer, sitting at a wooden desk with a laptop. She is surrounded by various icons: a clock, a speech bubble with 'Hi', a question mark, a speech bubble with a person, an envelope, and a globe.

You can email to
Clabel.service@outlook.com
for more help!