

Avigilon Unity Access Mobile App

User Guide

© 2021 - 2023, Avigilon Corporation. All rights reserved. AVIGILON, the AVIGILON logos, ACCESS CONTROL MANAGER and ACM are trademarks of Avigilon Corporation. Android is a trademark of Google LLC. Apple, iPhone, and iPad are trademarks of Apple Inc. Other names or logos mentioned herein may be the trademarks of their respective owners. The absence of the symbols ™ and ® in proximity to each trademark in this document or at all is not a disclaimer of ownership of the related trademark.

This document has been compiled and published using product descriptions and specifications available at the time of publication. The contents of this document and the specifications of the products discussed herein are subject to change without notice. Avigilon Corporation reserves the right to make any such changes without notice. Neither Avigilon Corporation nor any of its affiliated companies: (1) guarantees the completeness or accuracy of the information contained in this document; or (2) is responsible for your use of, or reliance on, the information. Avigilon Corporation shall not be responsible for any losses or damages (including consequential damages) caused by reliance on the information presented herein.

Avigilon Corporation
avigilon.com

PDF-UAMA-UG-1.12-A

Revision: 1 - EN

20230928

Revisions

Release	Description
Avigilon Unity Access mobile app 1.12	Formerly, ACM Expedite

Table of Contents

Revisions	3
Before You Start	5
App Features	5
Device Requirements	5
System Requirements	5
Install or Upgrade the Avigilon Unity Access Mobile App	6
Add a Connection to an ACM Appliance	7
Activate a Connection	7
Edit a Connection	7
Delete a Connection	7
Global Actions	8
View Global Actions and Details	8
Run a Global Action	8
Doors	9
View Doors and Details	9
Issue Commands to a Door	9
View Door Transactions and Status	9
Identities	10
View Identities and Details	10
Update Identity Status	10
Favorites	11
For More Information	12

Before You Start

The Avigilon Unity Access mobile app gives operators quick access to their access control system.

App Features

- Review recent transactions, real-time status, and grant access to installed doors from your mobile device.
- Access global actions to issue commands, such as locking down doors connected to more than one panel or subpanel, from your mobile device.
For example, a delivery person is delivering a package to a door at the back of the office building. The office receptionist, who is seated at the opposite side of the building, uses the app to open the door remotely with a couple of taps and reviews the door transactions to ensure the delivery person was able to enter the premises.
- View identities including their personal and contact information, tokens, roles, and groups; and update their status from your mobile device.
The token types include mobile credentials, badges, biometrics, Personal Identification Verification (PIV) cards for government employees, and PIV-Interoperable (PIV-I) cards for government contractors.
- Dark mode support by enabling the dark mode setting on your device.

Device Requirements

- Android™ 5 or later for smartphones and tablets
- iOS 11.4 or later for Apple® iPhone® and iPad® mobile devices



System Requirements

- Access Control Manager™ release 6.22 or newer

Note: To benefit from the latest features in ACM and the Avigilon Unity Access mobile app, you need to upgrade to the newest releases. You may need to install or upgrade to the latest release of the Avigilon Unity Access mobile app to connect to the ACM appliance.

- ACM account
- Network access from the mobile device to the ACM appliance

Install or Upgrade the Avigilon Unity Access Mobile App

1. Go to  or .
2. Install and open the Avigilon Unity Access mobile app.
3. Read and accept the End User License Agreement (EULA) for the mobile app.

Add a Connection to an ACM Appliance

Note: Contact your ACM administrator for help with entering connection information.

1. Tap the **Add** button in the Available Systems card.
2. Enter:

Title	The ACM appliance to connect to.
Host Name	The domain name or IP address of the ACM appliance.
Port	The port on the ACM appliance.
User Name	The user name of your ACM account.
Password	The password of your ACM account.
3. Tap the **Add** button.
4. Repeat the previous steps for each ACM appliance that you need to connect to.

Activate a Connection

- In the list of available systems, tap the ACM system you want to connect to and then tap the **Connect** button.
You are connected to the ACM system.
- *Android devices only.* If prompted, tap the **CONTINUE** button to accept the self-signed SSL certificate for the ACM appliance.

Edit a Connection

- Select an ACM system and tap the **Edit** button.

Delete a Connection

- Edit a connection and tap the **Delete** button.

Global Actions





(missing or bad snippet)

Note: Global actions and permissions are configured by your administrator. If none is configured, you will not see any global actions in the Avigilon Unity Access mobile app.

Before you start, see *Install or Upgrade the Avigilon Unity Access Mobile App* on page 6 and *Add a Connection to an ACM Appliance* on the previous page.

View Global Actions and Details

To view the global actions list, do one of the following:



- Tap  **Global Actions** after connecting to an ACM appliance for the first time.
- Tap  and then  **Global Actions**.
- Tap  in the bottom menubar.

All the global actions that you have access to on the ACM appliance are displayed.

- Enter the name or type of global action in the **Search** box to find it quickly.
- Tap on a global action from the list to view its details.

Run a Global Action

On the global actions list, do one of the following:

- Tap an action. On the global action details page, tap the  **RUN** button.
- Swipe left on a global action and then tap the  **RUN** button. The action is initiated.





Doors

Review recent transactions, real-time status, and grant access to installed doors from your mobile device.

Note: Only installed doors are displayed. Before you start, see *Install or Upgrade the Avigilon Unity Access Mobile App* on page 6 and *Add a Connection to an ACM Appliance* on page 7.

View Doors and Details

To view the doors list, do one of the following:



- Tap  **Doors** after connecting to an ACM appliance for the first time.
- Tap  and then  **Doors**.
- Tap  in the bottom menu bar.

All the installed doors that you have access to on the ACM appliance are displayed.

- Enter the name of the door in the **Search** box to find it quickly.
- Tap on a door from the list to view its details.

Issue Commands to a Door

On the doors list, do one of the following to remotely grant access:

- Tap a door. On the door details page, tap the  **Grant Access** button.
- Swipe left on a door and then tap the  button.

View Door Transactions and Status

The recent transactions are displayed on the door details page:

- Tap **View More** in Recent Transactions to view more transactions.

When known, changes to the active state of a door and status are displayed in the **Real-time status** card.

Identities





View identities including their personal and contact information, tokens, roles, and groups; and update their status from your mobile device.

Note: Identities are configured by your administrator. If none is configured, you will not see any identities in the Avigilon Unity Access mobile app.


Before you start, see *Install or Upgrade the Avigilon Unity Access Mobile App* on page 6 and *Add a Connection to an ACM Appliance* on page 7.

View Identities and Details

To view the identities list, do one of the following:

- Tap  **Identities** after connecting to an ACM appliance for the first time.
- Tap  and then  **Identities**.
- Tap  in the bottom menubar.

All the identities that you have access to on the ACM appliance are displayed.

- Enter the details of the identities in the **Search** box and then tap  to find them quickly. For example, type the first name, middle name, or last name.
- Tap on an identity from the list and then tap **View More** to view the details of the identity, tokens, roles or groups.

Update Identity Status

On an identity page:



- Tap the current value in **Status** to change it.

Note: Deactivating an identity will set their tokens to Inactive.

- Tap **Cancel** to return to the identity details page.

Favorites

On the details page of a door, global action or identity; or after swiping right on the door, global action or identity, do any of the following:

- Tap the  icon to add a door or global action to your favorites list.
- Tap the  icon to remove a door or global action from your favorites list.
- Tap the **Favorites** button to view only favorites.

For More Information

For additional product documentation and software and firmware upgrades, visit support.avigilon.com.

Technical Support

Contact Avigilon Technical Support at support.avigilon.com/s/contactsupport.