



Mini Soundbar

**NEO VITA BAR**  
**201**



**User Manual**

[www.zebronics.com](http://www.zebronics.com)



Thank you for purchasing **ZEB-VITA BAR 201** Mini Soundbar. Please read the user manual carefully before usage & save it for future reference.

Note:

- Avoid the use of this product in high-temperature and high-humidity environments.
- Avoid the self-disassembly of the products or it results in voiding the product's Warranty.
- Please charge the product with power adaptor output rated voltage DC 5V

*<https://zebronics.com/pages/warranty-policy>*

## Features

BT v5.3

USB & AUX

Powerful Dual Drivers

LED Indicator

Dual passive radiators

Media / Volume control

Type-C Charging

## Specifications

Model No. : ZEB-PSPK 41

Output Power (RMS) : 30W (15W +15W)

Driver Size : 5.7cm x 2

Impedance :  $2\Omega$  x 2

Frequency response	: 70Hz-20kHz
S/N Ratio	: $\geq 78$ dB
Separation	: $\geq 55$ dB
File format support	
(USB)	: MP3 & WAV
Line input	: 3.5mm
Max supported memory size	
(USB)	: 128GB
BT name	: ZEB-VITA BAR 201
BT version	: v5.3
Charging Time	: 5h
Playback time	: 8h*
Product Dimension	
(W x D x H)	: 40.4 x 8 x 6.3 cm
Net.Weight	: 827 g

*\* at 50% Volume*


### **Package Contents**

Speaker	: 1 U
Charging Cable	: 1 U
AUX Cable	: 1 U
QR code Guide	: 1 U

### **Charging Instruction:**

Use the provided Type C charging cable with a DC 5A/1A rated power adapter/charger

## Button Description:



## Port Description:

- 1** Play/Pause
  - Single-Press to Play/Pause Track in BT/USB & Mute/Unmute in AUX.
  - Long-Press to Disconnect/Reconnect the BT Connection
- 2** Previous
  - Single Press to Previous Track (BT & USB)
  - Long Press to Rewind the Current Track (USB)
- 3** Volume Down  
Single/Long Press to Volume Down
- 4** Volume Up  
Single/Long Press to Volume Up
- 5** Mode  
Single-Press to switch between available Input Modes
- 6** Next
  - Single Press to Next Track (BT & USB)
  - Long Press to Fast Forward the Current Track (USB)
- 7** LED Indicator  
BT Mode : BLUE  
AUX Mode : RED  
USB Mode : PINK

- 8 AUX Input (Works only when AUX cable is Plugged In)
- 9 USB Input (Works only when USB is Plugged In)
- 10 Type-C Charging
- 11 Charging Indicator
  - Charging LED Stays RED
  - Full Charge: LED Goes OFF
- 12 Power ON/OFF

### **BT Connection:**

Use the “**M**” button to switch the input to BT mode, You will hear a notification voice indicating BT mode and Blue LED flashes near M button. Now turn on turn on BT in your source device settings and tap on **ZEB-VITA BAR 201** and click pair. You will hear a notification voice indicating the pairing was successful.

### **USB Input:**

Plug a pen drive into the USB port, and the speaker will switch automatically to USB mode and start playing the supported audio files.

### **AUX Input:**

Plug in the provided aux input cable to the speaker and plug the other end to any compatible audio output device.

***Note:** Media controls can be controlled only via audio source device*

**ISO 9001:2015 Certified Company**  
**[www.zebronics.com](http://www.zebronics.com)**

