


3- Remove the black nozzle and oil tube from the diffuser with the metal hook.

4- Install the spare nozzle, making sure it's tight enough.

5- Screw the fragrance oil bottle in the Diffusion Head.

6- Install the Diffusion Head back on the diffuser.

7- You are ready to use your diffuser.



CE FC RoHS

Scentsment, LLC, Miami, FL 33122

How to clean the diffuser

For best performance:

If the machine is unused for a while, clean the container with Scentsment's Diffuser Cleaner solution, filling it almost to the top of the oil bottle.

Clean the Mini Diffuser 2 every 1-2 months:

- Remove the Diffusion Head.
- Replace the oil bottle with a 20 ml Scentsment Diffuser Cleaner Bottle or fill the provided plastic bottle with Scentsment's Diffuser Cleaner and reinstall securely.
- Install the Diffusion Head back in the Mini Diffuser 2.
- Let the Diffuser run for two hours to ensure thorough cleaning.

Important Note: Place the diffuser in a very ventilated area when using the Diffuser Cleaner. For your safety, refrain from directly inhaling the mist emitted from the diffuser as it may pose risks to your respiratory system.

For general cleaning, use a damp cloth to remove stains and fingerprints.

Safety

Is it safe for kids and animals?

Yes, our fragrance oils are safe to use around people, pets, plants, and furniture, 100% free of all Parabens, Formaldehyde, Color Additives, Synthetic Dyes, and Preservatives.

Warnings

For best results:

- Avoid turning over or tilting the product to prevent damage.
- Don't modify or disassemble it.
- Use within the recommended temperature range of 2°C to 35°C.
- When not in use for a while, remove the oil bottle and store it separately.
- Keep out of reach of children and pets.
- Normal shaking may cause sound due to the anti-dumping device.
- Atomization effect may vary based on the fragrance oil type.
- For optimal results, use fragrance oils.

Warranty


Your device comes with a 6-month limited warranty. Please ensure that you have proof of purchase in case a claim arises. Please note that the warranty is non-transferable. The following will not be covered under warranty:

- Damage caused by accidents or fire.
- Failure to use the device properly.
- If the device is repaired by a non-authorized dealer.
- Third-party parts are used in the machine.


Returns & Replacements

All returned items, whether for a refund, exchange, repair, or replacement, undergo inspection in our warehouse within a timeframe of 10 to 14 business days. If you haven't received an update from us within this period, feel free to reach out and inquire after the 14th business day mark.


Additional Resources



Additional Resources



Mini Diffuser 2 User Manual



Returns and Exchanges



Scent Diffuser Mini 2

User Manual

What's included in the box

- Scent Diffuser Mini 2
- Replacement Nozzle and Oil Pipe
- Empty 20 ml plastic oil bottle
- USB-A to USB-C Power Cable
- User Manual
- Metal Hook

Diffuser technical description

- Weight: 995 g
- Voltage: DC5V/1A
- Coverage: 500 sq ft
- Oil Bottle Capacity: 20ml
- Power: 5W
- Noise: <28 dba

Features



- **Immersive Scent:** Envelop spaces up to 500 square feet with your chosen fragrance, crafting a truly captivating ambiance.
- **Personalized Intensity:** Tailor the aroma to your preference with adjustable settings, from subtle hints to intoxicating waves.
- **Preserved Purity:** Our waterless, heatless technology ensures the fragrance oils remain pure and potent, delivering an authentic olfactory experience.
- **Immaculate Diffusion:** Enjoy a clean, residue-free diffusion that safeguards your valuable belongings and maintains a pristine environment.

Power Connection

Your Scent Diffuser Mini 2 will come with a power cable you can use to connect to any compatible power brick to charge the internal battery.

Connection Instructions:

1- Take your cable out of the box.



3- Plug the cable into a port, outlet, computer, or power brick.



- You will see the front Lightbar pulsing with a green light, indicating the device is charging.



2- Connect the Diffuser Mini 2 to the cable.



4- Enjoy the convenience of wireless charging with the Mini Diffuser 2. Simply place it on an existing wireless charging base to power up and enjoy favorite scents.



- After the battery is fully charged, the green light will remain still.



- Now you can unplug your Mini Diffuser 2.



Battery Alert

When the diffuser battery reaches 20% or a lower level, the lightbar will pulse with a red light every five seconds until it's completely depleted or connected to a power source.



How to add oil to the diffuser

Pair your Scent Diffuser Mini 2 with Scentiment's 20 ml oil bottles.

To replace the oil bottle:

- 1- Pull up the magnetic diffusion head of the diffuser. It will reveal the 20ml plastic bottle that comes with the diffuser.
- 2- Replace it with a 20 ml Scentiment Oil Fragrance Bottle or fill the empty plastic bottle with your preferred Scentiment fragrance.



3- Securely reinstall the diffusion head, ensuring correct alignment.



How to Use the Diffuser

To turn on/off the device press and hold the rear power button for 2 secs.



Misting Intensity Settings.

The Intensity Level can be changed by pressing the rear button.



- Low: It will mist for 15 seconds and then remain dormant for 90 seconds.
- Medium: It will mist for 30 seconds and then remain dormant for 60 seconds.



- High: It will mist for 60 seconds and then remain dormant for 30 seconds.



Connect your diffuser to Scentiment App

- 1- Scan the code to download the app.
- 2- Turn your diffuser on.



3- Open Scentiment App



4- Create an account.



5- Select "Connect My Device" and follow the prompts.



Scentiment's App will allow you to fully control your diffuser remotely. You can set a schedule for the diffuser to follow, with your desired misting intensity level to elevate your space with your favorite fragrances.

Factory Reset

To perform a factory reset, follow these steps:

- 1- Turn your diffuser off.
- 2- Press the rear button for five (05) seconds. The lightbar will blink with blue light, indicating that the factory reset was successful.



3- You can now turn your diffuser back on.



Note: Note: If your diffuser was connected to the Scentiment App, after the reset you will need to pair the diffuser again.

Replacing the Nozzle

In case your Diffuser Mini Diffuser 2 nozzle gets damaged, you can replace it with the spare nozzle that comes with your Mini Diffuser 2.

Follow these instructions to replace the nozzle:

- 1- Pull the Mini 2 diffusion headsection.
- 2- Unscrew the oil bottle and set it aside.



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction