

70mm

90mm

POWER BANK

1、Product Introduction

① Input

② Output

③ LOGO

④ Battery Display

②

POWER ev0

③

①

④

• Output

Wireless charging

• Input

Type-C

• Charging indicators

* Red light will be on when power bank is charged, and will turn off after 5 seconds.

* Green light will be on when power bank is fully charged, and will turn off after 5 seconds.

* Red light will be on when charging the device , and will turn off after 5 seconds.

* Green light will be on when the device is fully charged, and will turn off after 5 seconds.

2、Charging and discharging diagram

① Charging the power bank

Wall charger

Using a USB-A/Type-C cable to connect the wall charger to the power bank Type-C port

Type-C

② Charging your device

Output
Wireless charging

Connect the power bank wireless charging output to your device

Device

3. Usage Notes

• Initial Charging: Please fully charge this product before first use.

• Charging Connection:When using this product, ensure the digital device's screen is on and confirm that the charging connection icon is displayed correctly to ensure proper operation.

• Choosing Appropriate Cables: When charging this product or using it to charge digital devices, choose an appropriate connection cable.

• Connecting to Digital Devices: Use the standard data cable for the power bank or the standard data cable for the digital device to connect the digital device to the power bank. Generally, the power bank will automatically recognize and start charging. If not, please manually turn on the power bank.

• Low Power Indication: If all the LED indicators on this product are off during the charging process, it indicates that the product's battery is low, and you should charge it as soon as possible.

• Disconnect After Charging: When the digital device is fully charged, please promptly disconnect the cable to avoid unnecessary power loss.

⚠ WARNINGS

1. Do not use abrasive cleaners to clean this product.

2. Do not let this product overheat or be near open flames, such as stovetops.

3. Do not expose this product to direct sunlight for extended periods.

4. Do not dispose of this product in fire, as it may cause an explosion.

5. Do not attempt to disassemble or modify this product, as it does not contain any serviceable parts.

6. Do not use this product in the rain.

7. If the product is not intended to be used for a long time, store it in a dry environment, and charge it at least once a month to extend its lifespan. Avoid extreme temperatures and dust.

8. When in use, the product should be placed on a desktop; if it comes into contact with a human body, the contact time should be less than 10 seconds.

9. Power banks should not be used after being submerged in water.

材质:80 g双胶纸
尺寸:90X70mm
一折 双面印刷

FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.