


RG405V



RG405V User Manual

RG405V

Table of Contents

3.Language/Input/Brightness

1. Language setting

•Enter the Settings application , System-> Languages & input -> Languages -> Add a Languages -> select language item -> drag the language item to the top, the system language will be changed.

2. Enable input method

•Enter the Settings application, System> Languages & input>On-screen keyboard>manage on-screen keyboards >select input method switch>return to the select input> switch to the default input.

3. Brightness control

•pull down the Quick settings tile, set directly or enter the Settings application , select Display -> Brightness level to adjust.

4.RG Android Front-end Usage Instructions

1	Main Interface Operation:
2	Function Description
3	Language/Input/Brightness
4	RG Android Front-end Usage Instructions
5	RG Android Front-end Button Description
6	RG405V Game Button and Port

- Opening the Android Front-end
- On Android, click the RG icon in Quick settings tile to open the front-end.

When you enter the front-end for the first time, Click to confirm according to the prompt pop-up box, Pop up the RetroArch decompression resource process Exit RetroArch after decompression is complete, will return to the RG Front-end.

- Emulator interface:
- Short press SELECT: select and switch the emulator interface.

Long press SELECT: can hide/show the emulator.

Long press X key: Scan and refresh the game (after replacing a new TF card).
- Game list interface:
- START: Game search.

SELECT: Game setting.

X key: complete the game's collect and cancel.

1.Main Interface Operation:

Android main UI:

D-pad and joystick	Select application
A key / START key / Y key / touch screen	Confirm/Enter the application
SELECT key	Open menu
B Key	Cancel /Close menu
Volume key +/-	Volume adjustment
Return key	Short press RETURN / Long press HOME
Function key	Switch Android Front-end

5.RG Android Front-end Button Description

Button	Main interface of emulator	Game List Interface
A key	Confirm	Confirm
B key	Return (cancel)	Return (cancel)
X key	Scan refresh game	Collect
Short press SELECT	Emulator interface switching	Setting
Long press SELECT	Can hide/display the emulators	
START		Search function
D-pad key (joystick)	Moving cursor	Moving cursor

Note: Long press F key(HOME key) in the game running interface can return the Android front-end interface

2. Function Description

- First Boot up
- First Boot up can Select Language, Next need to wait for the first boot configuration to complete .
- Key mapping
- Open the Key mapping for the Quick settings tile, the usage window will pop up to the interface, For specific use, please refer to the application's internal usage details page instructions.
- Indicator light and charging function
- The machine packaging matches 5V/2A four-line charging data cable. Plug in the charging cable and the machine will start charging. The status of the device indicators is as follows: Red light on when charging, Green light on when fully charged, Red light twinkling when battery is low.

6.RG405V Game Button and Port

