



LOREX[®]

En

Wi-Fi Chime

ACCHM1 Series Quick Start Guide

lorex.com





What's included



Wi-Fi Chime



Power plug



Pin

Installation

To attach the power plug, hook the power plug's bottom tab into the chime slot and push in.





To detach the power plug, hold onto the plug then push up on the detach switch.







Wi-Fi Chime overview



Status indicator

-  **Solid blue**
Operating correctly.
-  **Flashing blue**
 - Ready for connection.
 - Network connection failed. Use the pin to reset.

Dimensions

Height: 3.9" (99mm)

Width: 2.0" (52mm)





App setup

1. Scan the QR code on this page to download the free **Lorex Home app** from the App Store or Google Play Store.
2. Open the Lorex Home app.
3. Sign in or sign up and create an account.
4. Plug the Wi-Fi Chime into a outlet.
5. Once the status indicator flashes blue and the startup chime sounds, tap the **+** icon.
6. Scan the device QR code on the chime and tap **Next** or tap **Manually enter Device ID**.
7. Follow the in-app instructions to complete the setup.



IMPORTANT

- Ensure you are on a 2.4 GHz Wi-Fi connection.
- Ensure your 2K Video Doorbell and Wi-Fi Chime have the latest firmware version in the device settings.





Link to the 2K Video Doorbell

There are two ways to link the Wi-Fi Chime to the 2K Video Doorbell.

- During the doorbell setup:
When the **Chime Type** screen appears, select your Wi-Fi Chime, then tap **Complete**.
- After the doorbell setup:
 - Tap the **•••** icon for the 2K Video Doorbell.
 - Tap **Doorbell Chime**, then tap **Wi-Fi Chime**.
 - Select your chime, then tap **Save**.





Copyright © 2021 Lorex Corporation

As our products are subject to continuous improvement, Lorex reserves the right to modify product design, specifications and prices, without notice and without incurring any obligation. E&OE. All rights reserved.



Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

For up-to-date information and support, please visit:
help.lorex.com

Please see our full Terms of Service and Limited Hardware
Warranty Policy at **lorex.com/warranty**

ACCHM1_QSG_TRILINGUAL_R1





Copyright © 2021 Lorex Corporation

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radioexempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.



This equipment complies with FCC/IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



ce matériel est conforme aux limites de dose d'exposition aux rayonnements, FCC / CNR-102 énoncée dans un autre environnement. cette equipment devrait être installé et exploité avec distance minimale de 20 entre le radiateur et votre corps.

ACCHM1_QSG_TRILINGUAL_R1

