

PETKIT

FRESH ELEMENT 3 INSTRUCTION MANUAL

Please read the User Manual before using this product and store the User Manual in an appropriate place.

TABLE OF CONTENTS

User warning	1
User safety guide	1, 2
List of components and parts	3
Product summary	4, 5
Quick setup (device setup)	6
Quick setup (opening top lid and adding food)	7, 8
Using the App	9
Indication lights	10
Cleaning the device	11, 12, 13
Installation guide	14, 15
FAQ	16
Basic specifications	17
Harmful Substances	17



Note: This User Manual can be used for the 3L and 5L versions of the PETKIT Fresh Element 3 Smart Pet Feeder. Each is operated in the same way. This User Manual uses the 3L version as an example.

USER WARNING

- Thank you for purchasing the PETKIT Fresh Element 3 smart Pet Feeder. PETKIT works hard to improve the lives of pet owners and pets alike through the use of technology.
- Before using, please carefully read the User Manual. By setting up or using the device, you agree that you have already read and accepted the safety guidelines listed below.
- PETKIT is not responsible, nor does it accept any legal responsibility for any accidents or losses caused by improper use of this device.
- PETKIT reserves the right to interpret and modify this notice.

USER SAFETY GUIDE


- **Failure to follow the safety guide outlined below may result in device malfunction or other unexpected accidents.**
- Only setup and use the device as instructed in the User's Manual.
- This device is not recommended for pets younger than 3 months.
- Please only use indoors.
- This device only uses a small amount of power, however it may still leak power if pets chew on the wire. Please guide the cat to use it correctly.
- Only use the provided power adapter. Otherwise, you may damage the device or cause a risk to safety.
- Please make sure the device is placed on a level surface. Do not overturn the device, or it may not function properly.
- Do not drop all items except pet dry food into the food storage container, or the device will not function properly, and it may even endanger the safety of the pet.

USER SAFETY GUIDE


- In order to prevent your pet from overturning this device, we recommend placing it in a corner or against a wall.
- When dispensing food, please do not obstruct the dispenser opening.
- It is forbidden to immerse or soak the main body of the device in water.
- If you plan on leaving this device unused and unpowered for long periods of time, use the power adapter to charge the device occasionally to avoid reducing the service life of lithium batteries.
- To avoid interfering with the scale function of the food bowl, do not place heavy items in the food bowl made of 304 stainless steel.
- Children should only be allowed to operate this device under the supervision of an adult.
- In order to avoid unnecessary damage or injury, only repair technicians should be allowed to repair this device.
- If you encounter any problems operating this device, please contact customer service at 400-087-0203.

LIST OF COMPONENTS AND PARTS

*Before setting up your device, please make sure you have all the necessary parts.




PRODUCT SUMMARY



Note: In order to provide a better product, we will make periodic product enhancements. If the illustrations do not match what you see on the device, please refer to the device as standard.


PRODUCT SUMMARY



QUICK SETUP (DEVICE SETUP)

1 Connect the power adapter

Take out the power adapter cord and attach it to the power adapter port on the bottom of the main device.



2 Device setup


1. Place the main device on a level surface.
2. Attach food bowl support to the main device.
The magnet guides should ensure it connects to the appropriate location on the main device and the 304 stainless steel bowl is placed in the correct position.
(No shown in the illustration below)



QUICK SETUP (OPENING THE TOP LID AND ADDING FOOD)

3 Open the top lid

Pull the buttons on the top lid to both sides, then lift the top lid up and out.



4 Insert Desiccant

Place the top lid on a level surface and open the desiccant compartment, lay the desiccant packet inside, then close the desiccant compartment.



QUICK SETUP (OPENING THE TOP LID AND ADDING FOOD)


5 Add Pet Food

Add pet food. (Do not exceed the Max line)
*Make sure the pellet size of the pet food is appropriate.



6 Put the top lid back on

Pull the buttons to both sides, at the same time, put the top lid back on.



7 Manually dispense food

Hold down to dispense food
Release button to stop dispensing food.



