



Rear view

Diagram showing the rear view of the device with numbered components:

- 5: Battery cover latch
- 6: Battery cover
- 7: Micro-USB port
- 8: Headset jack
- 9: Camera lens
- 10: LED flash
- 11: Micro-USB port
- 12: Micro-USB port
- 13: Micro-USB port
- 14: Micro-USB port
- 15: Micro-USB port

Diagram illustrating the connections for the UC3430 (Rear) panel. The panel includes ports for Power, Audio, HDMI, and USB-C. The connections are as follows:

- Control Device:** Connected to the RJ-45 port (labeled 8).
- Monitors:** Two monitors are connected to the HDMI ports (labeled 2).
- Power:** Connected to the Power port (labeled 9).
- Audio:** Two audio inputs are connected to the Audio ports (labeled 6 and 7).
- Video:** A Video Recorder or Camera is connected to the HDMI port (labeled 2).
- Laptop:** Connected to the USB-C port (labeled 5).

www.aten.com

