


# WATERPROOF Vibrating Massage Ball



**USER MANUAL** 

Save this manual for future reference.

# **MASSAGER PARTS**



#### **INSTRUCTIONS**

**Press power button** to turn on LED charging indicator lights up

Press power button again:

Turns on vibration **Low Speed** setting **1** (1st speed indicator LED lights up)

Press power button again:

Turns on vibration **Medium Speed** setting **2** (2nd speed indicator LED lights up)

Press power button again:

Turns on vibration **High Speed** setting **3** (3rd speed indicator LED lights up)

Press power button again:

Turns on vibration **Variable Speed** setting **4** (cycles through all 3 settings)

Press power button again:

Standby Mode

# **CHARGING YOUR MASSAGER**

Plug the included charging cable into the unit and plug the other end into any USB power source with a voltage range from 3.7V to 5.0V. such as cellphone charger, mobile power bank, laptop or desktop computer.

- When the unit is charging, red and blue LED lights will be flashing
- The unit will not work while its charging
- Charging time is 2-4 hours. Actual charging time depends on its remaining power
- When fully charged, the blue LED will remain steady

#### **MAINTENANCE**

- The unit will power off automatically when vibrating continuously for 15 minutes. This prevents the unit from overheating.
- Do not use the unit continuously under the third speed vibration mode for more than 60 minutes. Allow it to cool down.
- Do not throw, drop or slam the product in any way.
- The product has an IP65 waterproof standard. An IP65 rated enclosure gives protection against low pressure water jets from any direction, as well as condensation and water spray. Do not submerge in water.
- Do not disassemble, attempt to repair, or replace any part of the massager
- Keep the unit clean and dry. Use the storage bag when not in use.
- Dispose of packaging, batteries, and electronic products according to local environmental laws

### **SPECIFICATIONS**

Net Weight: 360g

Material: ABS + Silicone
Battery: DC3.7V 2400 mAh

Charging Time: 2-4 hours

Working Time: Maximum speed 90 min. (6 cycles)

15 mins per cycle

Motor: RPM 2000 at first speed

4000 at second speed

6000 at third speed

Motor working temperature: 149°F

#### ΔRRΔNTY

What is covered: Any defect in materials and workmanship.

For how long: 1 year from date of purchase.

What we will do: If your product is defective and returned within 30 days after the date it was purchased, we will replace it at no charge to you. If returned after 30 days but within 1 year of the date of purchase we will repair it or, at our option, replace it at no charge to you. If we repair your product, we may use new or reconditioned replacement parts. If we choose to replace your product we may replace it with a new or reconditioned one of the same or similar design. The repair or replacement will be warrantied under our standard one year warranty.

Limitations: Implied warranties, including those of fitness for a particular purpose and merchantability (an unwritten warranty that the product is fit for ordinary use), are limited to 1 year from the date of purchase. We will not pay for loss of time, inconvenience, loss of use of your product or property damage caused by your product or its failure to work, or any other incidental or consequential damages including personal injury. Some states do not allow limitations on how long an implied warranty lasts or the exclusion of limitation of incidental or consequential damages, so the above exclusions or limitations may not apply to you.

What we ask you to do: To get warranty service for your product you must provide proof of the date of purchase. Within 30 days of the date it was purchased, return your product to your place of purchase for immediate replacement. After 30 days, but before the end of the 1 year warranty period, you may contact us at shopempower.com to issue a return authorization. We suggest that you retain your original packaging material in the event you need to ship your product. When sending your product include your name, address, phone number, proof of date of purchase, and a description of the operating problem. After repairing or replacing your product we will ship it to your home within four weeks.

What this warranty does not cover: Among other things this warranty does not cover defects resulting from accidents, unauthorized repair, failure to follow directions, misuse, fire, floods, and acts of God. If your protection is not covered by our warranty, contact us at shopempower.com to determine whether we will repair your product and other repair information, including charges. We, at our option, may replace rather than repair your product with a new or reconditioned one of the same or similar design, the repair or replacement will be warrantied for one year. This limited warranty is the only one we give on your product, and it sets forth all our responsibilities regarding your product. There are no warranties that extend beyond the description set forth above.

**State law rights:** This warranty gives you specific legal rights and you may also have other rights which may vary from state to state.

EMPOWER is a registered trademark of Action Products Worldwide.