



Einhell

EXPERT



Robot Lawn Mower

FREELEXO 500 BT

Item No.: 4326363

Ident No.: 21031

Bar Code: 4006825653496

The Einhell FREELEXO 500 BT robot lawnmower is a member of the high-performance Power X-Change family which provides unlimited flexibility within the system family. It is controlled via app by Bluetooth and the settings of the robot lawnmower can be set to individual requirements. In addition, it has an intuitive keypad. Using the app the operating time of the Einhell FREELEXO can be precisely programmed for each specific day. The FREELEXO 500 BT includes everything needed for installation and operation of an Einhell robotic lawnmower of the FREELEXO Series. It is suitable for a lawns up to 500 m² and includes a 2,5 Ah battery, 130 m wire, 190 fastening hooks, 3 blades and 4 connecting clamps.

Features & Benefits

- PXC system battery - can also be used for other PXC products
- App using Bluetooth - user-defined robot lawnmower control
- Multi area mowing - for complex gardens
- Intuitive keypad
- Programmable operating time for each specific day
- Safety sensor system thanks to impact, tilt and lift sensors
- Anti-theft protection in form of PIN code and warning signal
- Rain sensor
- Cutting height adjustment (20-60mm)
- Suitable for slopes up to 35%
- Carry-handle for comfortable transport
- Automatic return to charging unit and charging
- Lawn areas up to 500 m²
- Incl. 2,5 Ah PXC Battery
- Wire 130 m
- Fastening hooks 190 pcs.
- Blades 3 pcs.
- Connecting clamps 4 pcs.



Technical Data

- Power	18 V
- Battery	18 V 2500 mAh Li-Ion
- Cutting width	18 cm
- Slope	35 %
- Cutting height adjustment	20 mm - 60 mm
- Recommended area	500 m ²
- Perimeter wire	130 m
- Hooks	190 Pieces
- Spare blades	3
- Connecting clamps	4 Pieces



Logistic Data

- Product weight (kg)	14.46
- Gross weight (kg)	18
- Dimensions single packaging	722 x 528 x 325 mm
- Pieces per export carton	1 Pieces
- Gross weight of export carton	18.1 kg
- Dimensions export carton	737 x 530 x 327 mm
- Container quantities (20"/40"/40"HC)	224 462 528

Illustrations can contain accessories, which are not included in standard extent of delivery

Illustration similar (in design), production-wise modifications reserved

GS mark belongs to the product itself only, excluded accessory

Generated at: 18.01.2022 13:58

Page 1

Available as special accessories

	Power X-Boostcharger 6A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory		2x 3,0Ah & Twincharger Kit PXC-Starter-Kit Item No.: 4512083 Bar Code: 4006825638509 Einhell Accessory
	18V 4-6Ah Multi-Ah PXC Plus Battery Item No.: 4511502 Bar Code: 4006825644210 Einhell Accessory		18V 2,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512097 Bar Code: 4006825646962 Einhell Accessory
	Installation Kit 500m2 Robot Lawn Mower Accessory Item No.: 3414010 Bar Code: 4006825646863 Einhell Accessory		Installation Kit 800m2 Robot Lawn Mower Accessory Item No.: 3414011 Bar Code: 4006825646870 Einhell Accessory
	Installation Kit 1200m2 Robot Lawn Mower Accessory Item No.: 3414012 Bar Code: 4006825646887 Einhell Accessory		18V 2,0Ah Power X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory
	18V 4,0Ah Power X-Change 1 Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory		18V 4,0Ah PXC Starter Kit 1 PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory
	Spare blades 12 psc Robot Lawn Mower Accessory Item No.: 3414020 Bar Code: 4006825648775 Einhell Accessory		Perimeter wire 50 m Robot Lawn Mower Accessory Item No.: 3414021 Bar Code: 4006825648782 Einhell Accessory
	Connecting clamps 4 psc Robot Lawn Mower Accessory Item No.: 3414022 Bar Code: 4006825648799 Einhell Accessory		Fastening hook 100 psc Robot Lawn Mower Accessory Item No.: 3414023 Bar Code: 4006825648805 Einhell Accessory
	2x2 Power X-Quattrocharger 4A Charger Item No.: 4512102 Bar Code: 4006825649536 Einhell Accessory		18V 2,5Ah Power X-Change Battery Item No.: 4511516 Bar Code: 4006825650518 Einhell Accessory
	Power X-Fastcharger 4A Charger Item No.: 4512103 Bar Code: 4006825650228 Einhell Accessory		18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory
	2x 5,2Ah & Twincharger Kit PXC-Starter-Kit Item No.: 4512108 Bar Code: 4006825652376 Einhell Accessory		Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory
	robot lawn mower garage Robot Lawn Mower Accessory Item No.: 3414024 Bar Code: 4006825654417 Einhell Accessory		18V Battery Charger 3,0A - PXC Charger Item No.: 4514095 Bar Code: 4006825655292 Einhell Accessory
	Power X-Car Charger 3A Charger Item No.: 4512113 Bar Code: 4006825655377 Einhell Accessory		2x 4,0Ah & Twincharger Kit PXC-Starter-Kit Item No.: 4512112 Bar Code: 4006825655766 Einhell Accessory
	2x 18V 2,5Ah PXC-Twinpack CB Battery Item No.: 4511524 Bar Code: 4006825656206 Einhell Accessory		2x 18V 5,2Ah PXC-Twinpack Battery Item No.: 4511526 Bar Code: 4006825656695 Einhell Accessory
	5,2Ah & 4A Fastcharger PXC-Starter-Kit Item No.: 4512114 Bar Code: 4006825656787 Einhell Accessory		Cleaning Kit Robot Lawn Mower Accessory Item No.: 3414025 Bar Code: 4006825657951 Einhell Accessory



Repair Kit
Robot Lawn Mower Accessory
Item No.: 3414026
Bar Code: 4006825657968
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory



18V 4,0Ah Power-X-Change Plus
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



18V 3,0 Ah Power-X-Change 2
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory