

[illegible]

WHAT'S IN THE BOX



Your HD video monitor package contains the following items. Save your sales receipt and original packaging in the event warranty service is necessary.

1 set of VIDEO CD's

Requirements

For mobile access:

- MyFree Baby 10Mbps mobile app

Networks	Wi-Fi
No network connection	2.4GHz or 5GHz Wi-Fi

For home connection:

- 1.5 Mbps x 2 Mbps or 3.1 Mbps x 0.8 Mbps upload bandwidth per baby unit

OVERVIEW

Baby unit overview

- 1 **Microphone**
- 2 **Camera lens**
- 3 **LED indicator**
- 4 **Light sensor**
- 5 **LID sensor**

- Flashes orange and green alternately when the baby unit is in pairing mode.
- Orange is steady on when the baby unit is connecting to the parent unit and is talking.
- Green is steady on when the baby unit is connecting to the parent unit and is not connecting to the parent unit.
- Flashes orange slowly when the baby unit is connecting to the parent unit.
- Flashes green slowly when the baby unit is connecting to the parent unit and is talking.
- Flashes orange and green quickly and alternately when the parent unit is in pairing mode.

- 6 **Flashed LID**
- 7 **Flashed LID**
- 8 **Flashed LID**
- 9 **Flashed LID**
- 10 **Flashed LID**
- 11 **Flashed LID**
- 12 **Flashed LID**
- 13 **Flashed LID**
- 14 **Flashed LID**
- 15 **Flashed LID**

- Allow you to see clearly as a clock surrounding.
- **Antenna**
- Connected to router with Wi-Fi.
- **Speaker**
- **Temperature sensor**
- **Power jack**
- **Threaded socket**
- **Pair/reset button**
- Press for three seconds to enter pairing mode.

Parent unit overview

- 1 **Microphone**
- 2 **LCD ON/OFF**
- 3 **Power**
- 4 **LID sensor**
- 5 **LID sensor**
- 6 **LID sensor**
- 7 **LID sensor**
- 8 **LID sensor**
- 9 **LID sensor**
- 10 **LID sensor**
- 11 **Microphone**
- 12 **LCD ON/OFF**
- 13 **Power**
- 14 **LID sensor**
- 15 **LID sensor**

- Press to move the selection bar leftward, upward, rightward or downward.
- While viewing image from the baby unit, press to move the selection bar leftward, upward, rightward or downward.
- Press to zoom in or zoom out.
- Press to move the selection bar leftward, upward, rightward or downward.
- Press to move the selection bar leftward, upward, rightward or downward.
- Press to enter the menu.
- While in a menu, press to choose an item, or save a setting.
- **Zoom in**
- **Zoom out**
- **VOL+/VOL-**
- **Power jack**
- **Antenna**
- **Temperature sensor**
- **Pair/reset button**
- **Battery compartment cover**
- **Stand**

[illegible][illegible]

PROTECT YOUR AND ONLINE SECURITY



With care over your privacy and peace of mind. Think you've put together a list of online services you consider safe? Let's take a look at some of the ways you can ensure your wireless connection is secure.

Ensure your wireless connection is secure.

- Turn off your wireless router's wireless signal if you expect to be sleeping.
- The WPA2-PSK with AES setting is your router's wireless security menu.

Change default settings:

- Change your wireless router's default network name (SSID) to something unique.
- Change your wireless router's default network password to a strong password.
- If it isn't too tedious, change your router's default login password.
- Is complex.
- Does not contain dictionary words or personal information.
- Contains a mix of uppercase letters, lowercase letters, special characters and numbers.

Keep your devices up to date.

- Wireless routers can be hacked, so make sure you keep your router up to date.
- If you have a laptop, make sure you have the latest security updates.
- If the feature is available, enable automatic updates for future releases.



Disable Universal Plug and Play (UPnP) on your router.

- UPnP enabled on a router can limit the effectiveness of your firewall by allowing other devices on your network to bypass your firewall.
- A virus or other malware program could use this function to compromise security for the entire network.

For more information on wireless connections and protecting your data, please review the following links:

1. Federal Communications Commission: Wireless Connections and Bluetooth Security Tips
www.fcc.gov/consumers/guides/wirelessconnectionsandbluetoothsecuritytips
2. Microsoft: Internet of Tomorrow Security: Before You Connect a New Computer to the Internet
www.microsoft.com/windows/iot/InternetofTomorrowSecurity/SID-5303
3. Federal Trade Commission: Using IP Cameras Safely
www.ftc.gov/ftc/privacyandsecurity/usingipcamerasafely
4. West Atlantic: Discover What Security Means for Your Business
<http://www.westatlantic.com/what-security-means-for-your-business/>

CONNECT, CHARGE AND POWER ON THE BABY UNIT



Connect the baby monitor

NOTE

- Use only the power adapter supplied with this product.
- Connect the power adapter and the baby unit and connect the power adapter and the battery unit to the two-wire controlled cable or cables.
- Connect the power adapter to a wall outlet or power outlet.
- To reduce the weight of the parent unit and the baby unit, the parent unit and the baby unit may be connected to the power adapter by a single cable or multiple cables. Otherwise, the adapter may not be used.
- Make sure the power adapter, the baby unit, and the battery unit are not used near water.
- Power adapter cables are not for use of children.
- Do not use the power adapter with other electrical appliances, as the baby unit is at least 20 cm from reality products.

Connect and power on the baby unit

- Connect the power adapter to the baby unit and a power outlet.
- Slide the **ON/OFF** switch **INWARD** to power on your baby unit.

NOTE

- When power is up, the baby unit's status LED turns on. It indicates the baby unit is powered on.
- The status LED is only for visual aid. If you want to help the baby unit, press **MENU** when go to the LED on.
- Press **LED** and turn it on.

NOTE

- Some lens and surface may get warm during normal operation.

Install and charge the parent unit

Install the parent unit battery

The parent unit runs on rechargeable battery of AC power. To continuously monitor your baby, the parent unit must be charged by the power. With the battery fully, the parent unit can last **approximately 10 hours** for a real-time only.

NOTE

- Use only the battery supplied with the product.
- Do not use the battery for other than charging and discharging.

1 Insert the battery into the compartment cover to pull.

2 Press the compartment cover to pull.

3 Turn the battery cover open.

4 Make sure the battery is inserted correctly.

5 Point the external antenna for better reception.

6 Plug the power adapter into the AC power outlet.

7 Plug the power adapter into the battery pack.

Notes

- Before using the battery receiver for the first time, charge the battery for 12 hours.
- The power indicator lights on the monitor battery, battery for AC power, and the battery for the battery receiver are all lit. The power indicator lights on the monitor battery, battery for AC power, and the battery for the battery receiver are all lit. The power indicator lights on the monitor battery, battery for AC power, and the battery for the battery receiver are all lit.
- The power indicator lights on the monitor battery, battery for AC power, and the battery for the battery receiver are all lit. The power indicator lights on the monitor battery, battery for AC power, and the battery for the battery receiver are all lit.
- When the power indicator lights on the monitor battery, battery for AC power, and the battery for the battery receiver are all lit, the battery is fully charged.
- When the power indicator lights on the monitor battery, battery for AC power, and the battery for the battery receiver are all lit, the battery is fully charged.

Battery indicator status	Battery status	Action
The screen displays and .	The battery was very little used.	Charge without interruption (about 30 minutes).
The screen displays and .	The battery is fully charged.	Use the battery for only a short time.
The screen displays and .	The battery is fully charged.	Use the battery for only a short time.

PARENT UNIT ICONS	
Main Menu Icons	Options
  	Monitoring mode: (For VPM02 only) • Turn on/off monitoring mode • Single play 1 or 1 in 4
	Multi play: • View child status in Parent mode • Turn on/off multi play with baby unit in Split screen
 	Medicine and soothing sounds • Select play all medicines, or play one of the five medicines at a time • You can also set the timer to stop playing after 15, 30 or 40 minutes, or playing continuously
	Alerts - Sound, motion and temperature • Select the sound and motion detection alerts • Turn on/off sound and motion detection alerts • Select the temperature alarm temperature for alert range • Turn on/off temperature alert • Turn on/off Auto Wake Up function
 	Parent unit settings • Adjust parent unit screen brightness • Turn on/off dim mode
	Baby unit settings • Turn on/off Night Vision • Adjust baby unit screen LED volume • Adjust baby unit's speaker volume • Update baby unit's security key
Main Menu Icons	Options
 	Green Wi-Fi settings • Turn on/off Wi-Fi network connection • Connect mobile phone • Turn on/off Low Latency Tone • Turn on/off Low Latency Tone
	Substatus icons  Direct mode (For VPM02 only)  Baby unit 1 and baby unit 2 are connected to each other directly  Baby unit 2 and baby unit 1 are connected to each other directly  Router mode  Parent unit is connected to Home Wi-Fi network  Baby unit 1 and baby unit 2 are both connected to Home Wi-Fi network  Baby unit 2 and baby unit 1 are both connected to Home Wi-Fi network  Split mode (For VPM02 only)  Night vision is turned on  Night vision is turned on  Monitor alert is turned on  Monitor alert is turned on  6-level sound indicator  6-level sound indicator  6-level sound indicator  6-level sound indicator  Parent unit speaker is muted  Parent unit speaker is muted

BASIC OPERATION

Use the menu
Press **MENU/SELECT** to enter the menu. Choose a menu item, or save a setting. You can use the parent unit menu for advanced settings or operations, such as to **play** or **stop** the baby unit lullaby, or adjust the sound detection setting.



Write in the menu:

- Press **A**, **V**, or **Δ** to scroll among the menu options.
- Press **MENU/SELECT** to select an item.
- Press **TALK** to return to the live video
- Press **@** to go to **Help & Info** page.

TEST THE LOCATION FOR THE BABY UNIT



Driven by system updates, the software, online help topics, and online FAQs will be updated periodically.

- Go to <https://help.vicphones.com/vm901> or <https://help.vicphones.com/vm901-2>. OR
- Scan the QR code on the right. Launch the camera app or QR code scanner app on your smartphone or tablet. Hold the device's camera up to the QR code and frame it. Tap the notification to trigger the redirection of the online help.



TEST THE SOUND LEVEL AND POSITION THE HID VIDEO MONITOR

Testing the sound level of the HD video monitor

① **Cut off** the power supply of the video monitor. Then, make the speaker unit in the monitor move 10 centimeters away from the baby unit. If you hear any high-pitched noise from the parent unit, remove the parent unit and attach the video monitor to the baby unit. You can also press **VOX** on the parent unit to power off the noise reduction.

② **Tip** Turn the parent unit speaker volume down to the lowest unit.



- Keep the baby unit out of the reach of your baby. Never place or mount the baby unit inside the baby's crib or playpen.

2. Adjust the angle of the baby unit to aim at your baby. Refer to the online help on how to use the Pan/tilt and Zoom functions of the baby unit.

MOUNT THE BABY UNIT (OPTIONAL)

1. Place the wall mount bracket on a wall and then use a pencil to mark the top and the bottom holes as shown. Remove the wall mount bracket and drill two holes in the wall (7/32 inch drill bit).

4. Place the baby unit on the wall mount bracket. Tighten the screw into the threaded socket at the

5. You can maximize your baby unit's viewing angles by tilting the wall mount bracket. Hold the baby unit, and then rotate the knob in anticlockwise direction. This will loosen the knob. Tilt your baby unit up or down to adjust to your preferred angle. Then, rotate the knob in clockwise direction to secure the angle.

➤ GENERAL PRODUCT CARE

Clean with a soft cloth.
DO NOT immerse the parent unit and the baby unit in water and do not clean them under the tap.
DO NOT use cleaning spray or liquid cleaners.
Make sure the parent unit and the baby unit are dry before you connect them to the mains again.

STORAGE

3.8A FREQUENTLY ASKED QUESTIONS

FREQUENTLY ASKED QUESTIONS

Why does the baby unit not respond normally?

Try the following (in the order listed) for common cure:

1. Disconnect the power to the baby unit.
2. Wait a few minutes before connecting power back to the baby unit.
3. Reboot the parent unit.

Other electronic products may cause interference with your baby unit. Try installing your baby unit as far away from these electronic devices as possible.

The parent unit speaker volume may be too low. Press **VOL+** to increase the volume.

Why don't I hear a sound? Why can't I hear my baby cry?

You may have set a low sound sensitivity level. Set the sound sensitivity to a higher level. For details, go to www.philips.com/onlinehelp.

DOWNLOAD APP FOR MOBILE ACCESS

Alternatively, you can download the mobile app from the App Store or Google Play store.

OR

Scan the QR codes on the right to get the app.

- iOS 8.0 or later.
- 2 After installing the mobile app, follow the instructions in the mobile app and parent unit to set up and pair your baby unit.

LIMITED WARRANTY

What is not covered by this limited warranty?

This limited warranty does not cover:

1. Product that has been subjected to misuse, accident, shipping or other physical damage, improper installation, abnormal operation or handling, neglect, inundation, fire, water or other liquid intrusion, or
2. Product that has been damaged due to repair, alteration or modification by anyone other than an authorized service technician.

4. Product to the extent that the problem is caused by use with non-VTech accessories, or
5. Product whose warranty/quality stickers, product serial number plate or electronic serial numbers have been removed, altered or rendered illegible; or

What must you return with the Product to get warranty service?

1. A description of the problem and a description of the Product to be returned.
2. Include a "valid proof of purchase" (receipt identifying the Product purchased (Product model) and the date of purchase).
3. Provide your name, complete and correct mailing address, and telephone number.

Other limitations

[illegible]