



智能无线麦克风

SMART WIRELESS MICROPHONE

给你一个声音
GIVE YOU A VOICE

型号/Model: U18





电源开关 ① The power switch

短按音量加/长按调频 + ② Short press volume +/ long press frequency +

模式键(延时/混响/高/中/低音/ ③ Short press volume down/long press frequency modulation
电池电量)

短按音量减/长按调频 - ④ Infrared lamp

红外发射灯 ⑤ Display tube

显示管 ⑥ Mode button(delay/reverberation/high/medium/low /battery power)

Micro-B充电口 ⑦ Mini USB

拾音头 ⑧ cartridge

参数/Product Parameters

Frequency range:	740.15~769.85MHz
Modulation method:	FM fixed frequency
Audio response:	40hz--15khz
Dynamic range:	>100db
Audio output:	300mv
Receiver power supply voltage:	18650 lithium battery
Receiver working current:	<120mA
Receiver continuous use time:	(3.7V/1200mA)7-10 hours
Transmitter power supply voltage:	lithium battery
Transmitter working current:	<120mA

请注意/Please note that

- 1、不可将产品扔到火中、水中；
1. Do not throw the product into fire or water.
- 2、不得在医院内、机场附近等免干扰场所使用；
2. It shall not be used in the hospital, near the airport and other places without interference.
- 3、本机未含有可改装之部分, 请勿自行拆装, 否则您将失去保修的权利；
3. The machine does not contain any part that can be refitted. Please do not disassemble it by yourself, otherwise you will lose the right of warranty.
- 4、如本机摔落或有异物进入机体内, 请勿继续使用, 应立即与当地经销商或公认的服务中心联络。
4. If the machine falls or foreign matter enters the body, please do not continue to use it, and should immediately contact the local dealer or recognized service center.

- 1、使用时应避免放置死角以保持信号接收的良好。
- 2、使用头戴咪时请勿抛.摔.扔丢等以免造成严重损坏
- 3、机身不防水，应避免水滴直接进入机身或日晒或雨淋。
- 4、尽量远离电磁声场，高压输电网，大件金属物。
- 5、请勿私自拆开，内有可能伤及你身体的高压。
- 6、更换头戴咪时,务必首先将开关定于OFF(关)的位置
- 7、头戴咪如果长时间不使用时,请取出电池,以防电池漏液

8、接收机如果才时间不使用时，请拔掉电源插座。

9、头戴咪电池请勿新旧混用。

1. When the host machine is in use. it should avoid putting dead angle to keep signal connection Good harvest.

2. Do not throw, fall, or throw when using a headset to avoid serious damage.

3. The fuselage is not waterproof, and water drops should be avoided to enter the fuselage directly or Sun or rain.

4. Keep away from the electromagnetic sound field as far as possible high-voltage transmission network, big goid Belong to.

5. Please do not open it without permission.It may hurt your body because of the pressure.

6. When changing the microphone or headset, be sure to switch the switch to the OFF position.

7. If the microphone or headset is not in use for a long time, please remove it Remove the battery to prevent the battery from leaking

8. If the receivers have not been in use for while, please unplug it socket.

9. Do not mix old and new batteries with the headset.

