

# SALSA **BLUETOOTH SPEAKER**



User Manual

Model: MyBat Pro Salsa

## SAFETY MEASURES

Thank you for choosing the MYBAT PRO series of Bluetooth speakers. In order to make it easy for you to experience the product, we have prepared detailed instructions for use, from which you can get the product introduction, usage methods and other knowledge. Please read the instructions carefully before using this machine

- 1. Protection of power supply wire: Do not place the cable in the path of foot traffic. Do not place heavy furniture on the cable. Never pull the cable to unplug the unit from the socket, always disconnect the unit from the main power supply by pulling the plug out of the socket.
- 2. Ventilation: In order to prevent this unit from overheating, place it in a well-ventilated area on a stable surface. Never place it on a bed, sofa or carpet where the ventilation will be restricted.
- 3. Dismantling: In order to avoid the risk of electric shock, do not dismantle the unit. Should your unit be faulty or broken please refer servicing to an authorized service center.
- 4. Strange Odor: Should your unit emit any strange dour, immediately unplugit from the wall socket. Do not use the unit again until you have had it repaired by a qualified service center.
- 5. Do not expose this unit to liquid of any kind.

#### FEATURES

Digital tube display, master volume, reverberation, microphone volume knob a djustment, colorful lights with speakers.

# WHAT'S IN THE BOX

Microphone

OVERVIEW

Control panel

(at the back)

Speakers

Colorful Lights

CONTROL PANEL





Remote Control

User Manual

1 2 3 4 5 6 7 8

10 11 12 1314



4. Play / Pause

Single click: play or pause at TF/USB/Bluetooth mode.

Charge speaker via Micro USB charging cable.

Single click: next song at TF/USB mode, or next

Short press to automatically search channels at FM mode.

Press and hold to switch TWS mode.

1. Power Switch / Volume

2. Micro USB Charging Port

channel at FM mode.

Rotate to right: Power ON / Volume +

Rotate to left: Power OFF / Volume -

- 5. Digital tube display panel: Speaker status display
- 6. Previous

Next

Single click: previous song at TF/USB mode, or previous channel at FM mode.

7: Mode Switch / Light Switch

Single click to switch speaker mode (Bluetooth/ FM Radio/AUX/TF/USB drive).

Press 3S to turn ON or OFF the colorful lights. 8. ECHO

The reverberation intensity of the microphone is adjusted. The greater the opening, the more obvious the eFFect of the reverberation. When it is turned oFF, there will be no response.

9. MIC VOL

Adjust the volume of the microphone.

10 MIC IN

Plug in the microphone to use.

11 AUX IN

Connect the external audio source to the speaker via the audio cable.

12. USB


Connect to a USB storage device.

13. TF

Plug in the TF card to use.


14. Charging indicator

# REMOTE CONTROL PANEL



#### POWER ON

1. Please charge the unit at least 4 hours before first time using (after long time use, Speaker beeps 3 times and sound "power off", you need charge it)



2. Turn the knob on the panel to switch on the speaker




# 1.Bluetooth

CONNECTIONS




MyBat Pro Salsa


# 2. USB




#### 3. AUX



### 4. Microphone



### 5.TE card



### 6. TWS Dual Connection Mode

- Take two Salsa speakers, turn on one speaker, and enter the Bluetooth pairing mode. Turn on the phone's Bluetooth connection to the speaker.
- Turn on the other speaker and enter the Bluetooth pairing mode. Hold the Pause/Play button, and the two speakers can be paired successfully
- Either one of the two speakers can control up and down music/play/pause.
- After connecting once, the two speakers will be automatically paired the next time they are turned on, and there is no need to pair them
- To unpair the two speakers. Hold the Pause/Play button on any speaker.

### SPECIFICATIONS Product name: MyBat Pro Salsa

Power input: DC 5V Function: Support TWS/USB/TF/FM/AUX/MIC/Bluetooth Bluetooth solution: V5.3 Speaker specification: dual 8 inch

speaker Power: 40W

Product size: 240\*255\*626mm

Battery: 3.7V/3600MAH lithium battery

Battery charge time: 3 Hours

Battery playtime:5Hours at medium volume

Bluetooth range:10m

AWARNING: Cancer and Reproductive Harm www.P65Warnings.ca.gov









SCAN HERE TO CONNECT WITH US

# FCC Warning Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.