




go **SPKR**

WEARABLE BLUETOOTH CLIP SPEAKER WITH MAGNET




goSPKR Setup Guide

Scan the QR code or visit:


MEEaudio.com/goSPKRsupport

QUICK START GUIDE

what's in the box



goSPKR



Charging Cable

go **SPIKRR** interface

Multifunction button

Power on/off: Long press 3s

Play/pause: Press 1x

Siri® / Google Assistant™: Press 3x

Answer/hang up phone call: Press 1x

Reject incoming call: Long press 3s

Enable/disable stereo mode: Press 2x

Volume up button


Volume up: Press 1x

Next track: Long press 3s

Volume down button

Volume down: Press 1x

Previous track: Long press 3s




**HOLD
BOTH buttons**

5s


— Reset

charging ⚡



Step 1

Plug charging cable into a powered USB port



Step 2

Plug charging cable into goSPKR



red light = charging




green light = charged

Bluetooth pairing



Step 1

Power on



Step 2

Select MEE audio goSPKR on device

Note: To pair a different device, remove or disconnect the goSPKR from the Bluetooth menu of the original device




stereo mode



Stereo mode

Link 2 goSPKRs together for stereo sound!



Step 1

Connect the first goSPKR to your device

Step 2

Double press the  button on first goSPKR

Step 3

Power on the second goSPKR. Unpair it from any previously-paired Bluetooth device, then double press its  button

Note: Double press the  button on either goSPKR to exit stereo mode

WARNINGS

This device is designed and manufactured to operate within its defined design limits. Misuse may result in electric shock or fire. Read and follow these instructions carefully.

- Danger of explosion or fire if batteries are damaged. Never attempt to open the battery for any reason. Do not use the device if it has been crushed, pierced, or otherwise damaged in any way that could compromise the battery. Do not leave the speaker in any location with excessive heat including naked flames or near heat sources such as radiators and stoves. Do not expose the battery to spark, flame, or salt water.
- Do not charge or use around flammable gasses, liquids, or dust as fire or explosion may occur
- There are no user replaceable/reparable parts in the device. Disassembling it will void your warranty and may cause personal injury. Changes or modifications to this unit not expressly approved by MEE audio could void the user's authority to operate the equipment.
- Only use attachments/accessories specified by the manufacturer
- Keep the device and packaging out of the reach of children

SAFETY & CARE

- Using speakers at high volumes for extended periods of time will result in permanent hearing damage. It is advised you keep volume levels moderate to low at all times for your safety.
- The lifetime of the battery will be significantly reduced if your speaker is not charged for a long time. It is recommended to charge your speaker at least once a month.
- Battery performance will be severely decreased when stored in extreme temperatures. Do not store the speaker in locations where temperatures may reach below -10°C/14°F or above 40°C/105°F, including direct sunlight.
- Do not expose this product to rain or other moisture for an extended period of time. If submersed in water, do not turn the device on until completely dried. Note: liquid submersion voids the warranty.
- Do not use chemical cleaning sprays to clean this product. Only use a water-dampened cloth.

questions? we're here to help!

Phone Support: 626-965-1008
Monday ~ Friday 9 am to 5 pm PST

Email Support: support@MEEaudio.com
All emails are responded to within 2 business days

for additional support view our video setup guide

Scan the QR code or enter the
URL below into your web browser:

MEEaudio.com/goSPKRsupport



SPKR

WARRANTY

This product is covered by a 1-year manufacturer warranty.
For more information, visit MEEaudio.com/support.

MEE audio and its logo are registered trademarks of S2E, Inc. All rights reserved.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by MEE audio is under license. Other trademarks and trade names are those of their respective owners.

Siri® is a registered trademark of Apple Inc.
Google Assistant is a trademark of Google Inc.