Assembly Instruction 43516254 ALMA DESK

CARE INSTRUCTIONS:

WIPE CLEAN WITH A SOFT DAMP CLOTH.DO NOT USE ABRASIVE MATERIALS AND SOLVENTS.CHECK AND TIGHTEN ALL PARTS REGULARLY.DO NOT PLACE HOT ITEMS SUCH AS COFFEE CUPS DIRECTLY ON THE SURFACE.KEEP AWAY FROM WATER AND DIRECT SUNLIGHT.STORE IN A DRY PLACE.FOR DOMESTIC USE ONLY.FOR INDOOR USE ONLY.A MILD ODOUR MAY BE PRESENT WHEN FIRST OPENING THIS CARTON.SIMPLY ALLOW TO AIR OUTSIDE AND THIS WILL FADE. WARNING:


DO NOT STAND OR SIT ON THIS UNIT.DO NOT USE THIS UNIT UNLESS ALL BOLTS AND SCREWS ARE FIRMLY SECURED.DO NOT KNOCK OR DRAG THIS UNIT.USE ONLY ON A FLAT SURFACE. LOAD TOP EVENLY TO PREVENT FROM TIPPING OVER. THIS PACKAGE CONTAINS SMALL PARTS AND SHARP POINTS. KEEP AWAY FROM CHILDREN AND BABIES. ADULT ASSEMBLY REQUIRED. FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.


MAXIMUM SAFE LOAD:30KGS FOR TOP, 3KGS FOR DRAWER.

Hardware List

	Α	6x35mm	14pcs
	В		14pcs
	O	8x30mm	16pcs
(8)	D	4x35mm	12pcs
®	Е	3x12mm	24pcs
CLDL		300mm	2pcs
CR	·	300mm	2pcs
(D)	Н	7x40mm	6pcs

	I		24pcs
0	J		24pcs
_	K	4mm	1pc
Olympi	L	6x12mm	6pcs
Ommun	М	6x30mm	18pcs
	N		4pcs
(X)	0	3x16mm	4pcs





Part List

