





CUT ALONG THE LINE

Short instructions for the AVILOO FLASH Test – test the drive battery in 3 simple steps

CAUTION: Make sure the vehicle is not charging.



FLASH TEST SET UP

- Open the driver's door (leave it open during the test).
- VW, Skoda, Cupra and Seat Models: unlock the hood before plugging in the AVILOO Box (it is not necessary to open it).
- Plug the AVILOO Box into the OBD-2-port.
- Start the vehicle and leave the vehicle in park mode so that the systems necessary for the test remain active.
- Turn off the heating and air conditioning.
- **TIP:** The AVILOO WebAPP helps you locate the OBD-2-port in the vehicle.

2

PERFORM FLASH TEST

- Wait for the yellow flashing one LED indicating that the AVILOO Box is ready for the Flash Test.
- Fasten the driver's seatbelt to keep the systems necessary for the test active.
- Note for all Tesla Models: switch the vehicle to drive mode and keep your foot on the brake to prevent the vehicle from moving (due to the lack of an "ignition").
- Wait for the solid green LED, which indicates that the FLASH Test is complete.



END OF FLASH TEST

- Turn off the vehicle.
- Unbuckle the seat belt.
- Unplug the AVILOO Box.
- Close the driver's door and, if necessary, the hood.
- The AVILOO FLASH Test Report is sent by email to the email address stored for this AVILOO Box.

Please note:

Changes or modifications not expressly approved by Aviloo could void the user's authority to operate the equipment.

This is a mobile device and the user must ensure that they maintain a distance of 20 cm during operation.



Flashing green: data transfer.



Green light: Test completed.

FOLD HERE -

AVILOO BOX LED-DISPLAY



Flashing blue: indicates that the box is booting up.

DISPLAY IN THE AVILOO WEBAPP





Yellow light: test in progress.



If red lights up: FLASH Test failed (see notes at bottom right).

A FLASH



IMPORTANT NOTES:

- To keep the software up to date, leave the box plugged into the power supply when not in use.
- Red LED means: FLASH Test failed.

Take the following measures:



- Check at https://aviloo.link/database whether the vehicle can be tested
- 2. Repeat the FLASH Test according to the instructions.
- 3. Contact AVILOO Customer Support.

FOLD HERE